Micro: bit Starter Kit

keyestudio

Nov 30, 2023

KS4020 KS4021 EASY PLUG SUPER STARTER KIT FOR BBC MICRO:BIT

1	1.Des	scription	3					
2	2.Kit	List	5					
3	3.Int	3.Introduction to Micro:bit V2.0						
4	4.Ins	4.Install Micro:bit driver						
5	5.Get 5.1 5.2 5.3 5.4 5.5 5.6	ting Started with Micro:bit 5.1 Write code and program 5.2 Makecode 5.3 Quick Download 5.4 Resources and test code 5.5 Input test code 5.6 CoolTerm Installation	15 15 20 21 24 25 28					
6	6.Pro 6.1 6.2 6.3 6.4 6.5 6.6 6.6	vjects Project 1: Heartbeat Project 2: Light Up A Single LED Project 3: LED Dot Matrix Project 4: Programmable Buttons Project 5: Temperature Detection Project 6: Geomagnetic Sensor Project 7: Accelerometer	33 33 36 41 53 61 74 87					
	6.8 6.9 6.10 6.11 6.12 6.13 6.14	Project 8: Light Detection Project 9: Speaker Project 10: Touch-sensitive Logo Project 11: Microphone Project 12: Bluetooth Data Reading Project 13: LED Blink Project 14: Breathing Light	100 104 108 112 122 138 142					
	6.15 6.16 6.17 6.18 6.19 6.20 6.21 6.22	Project 15: Blink and Breath Project 15: Play Music Project 16: Play Music Project 17: RGB Project 18: Button Control Project 19: Tilt Control Project 20: Relay Module Project 21: Crash Sensor Project 22: Follow Black Line	144 147 151 157 160 162 165 167					

6.23	Project 23: Magnetic Detection
6.24	Project 24: 4-digit LED Display
6.25	Project 25: Light Interrupter
6.26	Project 26: EASY Plug Reed Switch Module 177
6.27	Project 27: Hear Footstep
6.28	Project 28: Rotary Potentiometer
6.29	Project 29: Alcohol Content in the Air 184
6.30	Project 30: Ambient Temperature Detection
6.31	Project 31: Water Level Alarm
6.32	Project 32: 1602 LCD Display
6.33	Project 33: Vapor in the Air
6.34	Project 34: Pressure Detection
6.35	Project 35: Make A Thermo-hygrometer

7 7.Resources



1.DESCRIPTION

Micro:bit is significantly applied to STEM education for teenagers, as a small microcontroller, which features small in size, easy to carry, and powerful function. At present, innovative technology products, like robots, wearable devices and interactive electronic games can be produced by programming and code.

MakeCode is a framework for creating interactive and engaging programming experiences for those new to the world of programming. The platform provides the foundation for a tailored coding experience to create and run user programs on actual hardware or in a simulated target.

To make you deeply know the micro:bit, we also provide test code and projects.

This super starter kit incorporates different sensors and modules such as passive buzzer, 1602 LCD module, RGB, crash sensor and so on. The detailed projects, from simple to difficult will spur your inspiration and bring in the magical programming world.

TWO

2.KIT LIST

#	Component	Quantity	Picture
0	Micro:bit board is Included in KS4021 Kit	1	
1	FASY Plug Shield for Micro bit V1.1	1	
2	EASY Plug While LED Module	1	
3	EASYP Plug Blue LED Module	1	
4	EASY Plug Red LED Module	1	
5	EASY Plug thin-film Pressure Sensor	1	() . keyvetudio
			Chapter 2. 2.Kit I

THREE

3.INTRODUCTION TO MICRO:BIT V2.0

What is Micro:bit?

Designed by BBC, Micro:bit main board aims to help children aged above 10 years old to have a better learning of programming.

It is equipped with loads of components, including a 5*5 LED dot matrix, 2 programmable buttons, a compass, a Micro USB interface and a Bluetooth module and others. Though it is just the size of a credit card, it boasts multiple functions. To name just a few, it can be applied in programming video games, making interactions between light and sound, controlling a robot, conducting scientific experiments, developing wearable devices and make some cool inventions like robots and musical instruments, basically everything imaginable.

The latest version, that's version 2.0, of Micro:bit main board has a touch-sensitive logo and a MEMS microphone. And there is a buzzer built in the other side of the board which makes playing all kinds of sound possible without any external equipment. The golden fingers and gears added provide a better fixing of crocodile clips. Moreover, this board has a sleeping mode to lower the power consumption of battery and it can be entered if users long press the Reset & Power button on the back of it. More importantly, the CPU capacity of this version is much better than that of the V1.5 and the V2 has more RMA.

In final analysis, the Micro:bit main board V2 can allow customers to explore more functions so as to make more innovative products.

Comparison between V2.0 & V1.5



Micro:bit main board V2.0



Micro:bit main board V1.5 More details:



	V1.5	V2				
PROCESSOR	Nordic Semiconductor nRF51822	Nordic Semiconductor nRF52833				
MEMORY	256KB Flash, 16KB RAM	512KB Flash, 128KB RAM				
INTERFACECHIP	NXP KL26Z, 16KB RAM	NXP KL27Z, 32KB RAM				
MICROPHONE	N/A	MEMS microphone and LED indicator				
SPEAKER	N/A	On board speaker				
TOUCH	N/A	Touch sensitive logo				
EDGE	25pins,PWM,I2C,SPI and Extension interface. 3 ring pins for connectin crocodile clips/banana plugs.					
CONNECTOR	3 dedicated GPIO	4 dedicated GPIO Notched for easier connection				
I2C	Shared (mux) I2C bus	Dedicated I2C bus				
WIRELESS	2.4GHz Radio/BLE Blutooth 4.0	2.4GHz Radio/BLE Blutooth 5.0				
POWER	Micro USB 5V power supply, 3V port or battery power supply	Micro USB 5V power supply, 3V port or battery power supply LED Indicator, Power off (push and hold power button)				
CURRENT AVAILABLE	90mA	200mA				
MOTION SENSOR	ST LSM 303					
PROGRAMMING SOFTWARE	, Python, Scratch					
SIZE	5cm(W) x 4cm(H)					

For the Micro: Bit main board V2, pressing the Reset & Power button, it will reset the Micro: Bit and rerun the program. If you hold it tight, the red LED will slowly get darker. When the power indicator becomes darker, releasing the button and your Micro: Bit board will enter sleep mode for power saving .This will make your battery more durable. And you could press this button again to 'wake up' your Micro:bit.

For more information, please resort to following links

https://tech.microbit.org/hardware/

https://microbit.org/new-microbit/

https://www.microbit.org/get-started/user-guide/overview/

https://microbit.org/get-started/user-guide/features-in-depth/

Pinout

Micro:bit main board V2.0 VS V1.5





Browse the official website for more details:

https://tech.microbit.org/hardware/edgeconnector/

https://microbit.org/guide/hardware/pins/

Notes for the application of Micro:bit main board V2.0

a. it is recommended to cover it with a silicone protector to prevent short circuit for it has a lot of sophisticated electronic components.

b. its IO port is very weak in driving since it can merely handle current less than 300mA. Therefore, do not connect it with devices operating in large current, such as servo MG995 and DC motor or it will get burnt. Furthermore, you must figure out the current requirements of the devices before you use them and it is generally recommended to use the board together with a Micro:bit shield.

c. It is recommended to power the main board via the USB interface or via the battery of 3V. The IO port of this board is 3V, so it does not support sensors of 5V. If you need to connect sensors of 5 V, a Micro: Bit expansion board is required.

d.When using pins(P3P4P6P7P10)shared with the LED dot matrix, blocking them from the matrix or the LEDs may display randomly and the

data about sensors maybe wrong.

e. The battery port of 3V cannot be connected with battery more than 3.3V or the main board will be damaged.

f. Forbid to use it on metal products to avoid short circuit.

To put it simple, Micro:bit V2 main board is like a micro computer which has made programming at our fingertips and enhanced digital innovation. And about programming environment, BBC provides a website: https://microbit.org/code/, which has a graphical MakeCode program easy for use.

4.INSTALL MICRO: BIT DRIVER

If you have downloaded micro:bit driver, then no need to download it again.

If it is you first time to use micro:bit main board, then you will have to download the driver.

First of all, connect the micro:bit to your computer using a USB cable.

And enter the link https://fs.keyestudio.com/KS4021-KS4021 to download the driver file of micro:bit,



mbed_usb_202 0_x64_1212.exe

5.GETTING STARTED WITH MICRO:BIT

The following instructions are applied for Windows system but can also serve as a reference if you are using a different system.

5.1 5.1 Write code and program

This chapter describes how to write program with the App Micro: Bit and load the program to the Micro: Bit main board V2.

You are recommended to browse the official website of Micro:bit for more details, and the link is attached below:

https://microbit.org/guide/quick/

Step 1: connect the Micro: Bit main board V2 with your computer

Firstly, link the Micro: Bit main board V2 with your computer via the USB cable.MacsPCs Chromebooks and Linux including Raspberry Pisystems are all compatible with the Micro: Bit main board V2.

Note that if you are about to pair the board with your phone or tablet, please refer to this link:

https://microbit.org/get-started/user-guide/mobile/



Secondly, if the red LED on the back of the board is on, that means the board is powered. Then Micro: Bit main board V2 will appear on your computer as a driver named 'MICROBIT'. Please note that it is not an ordinary USB disk as shown below.

💻 🛃 🔚 🖛 This PC		- 0	\times
File Computer V	/iew		~ 🕐
← → ~ ↑ 💻 > TI	his PC >	✓ Ö Search This PC	Ą
> 📌 Quick access	> Folders (7)		^
> 📃 This PC	 Devices and drives (3) 		
> 🚔 MICROBIT (E:)	en_windows_10_enterprise_ltsc_20 (C:)	Additions 0 bytes free of 56.9 MB	
> 💣 Network	MICROBIT (E:) 63.9 MB free of 63.9 MB	1	
11 items		-	

Step 2: writing programs

View the link https://makecode.microbit.org/ in your browser;

Click 'New Project';

The dialog box'Create a Project' appears, fill it with 'heartbeat' and click 'Create ' to edit.

(If you are running Windows 10 system, it is also viable to edit on the APP MakeCode for micro:bit , which is exactly like editing in the website. And the link to the APP is https://www.microsoft.com/zh-cn/p/makecode-for-micro-bit/9pjc7sv48lcx?ocid=badgep&rtc=1&activetab=pivot:overviewtab)



œmicro:bit	🖶 Home	🌣 📲 Microsoft
	Create a Project 🔮	
My Projects View All	Give your project a name.	± Import
Rew Project	>Code options	>

Write a set of micro:bit code. You can drag some modules in the Blocks to the editing area and then run your program in Simulator of MakeCode editor as shown in the picture below which demonstrates how to edit 'heartbeat' program .

As for loading test code, please turn to Chapter 5.5.

And introduction of Makecode is on the next chapter 5.2.

⊙micro:bit	🖀 Home	4	Blocks		us Jav	aScript	•		?	٠		Mic	rosoft
		Searci	n Q	on	start			foreve	r				
·Ø	μ.	⊙ II	nput					show	icon	. -			
		0 0 1 0 1	Ausic ed					show	icon	. -			
0 1 2	3V CND	ad B	adio										
	• 8	< CL XL	oops ogic										
		≡ •	ariables										
			dvanced										
<u>`</u> ••• •	· · · ·			-									-
📥 Downloa	d	heartb	eat		B	9					5	<u>م</u>	• •

Step 3: download test code

If your computer is Windows 10 and you have downloaded the APP MakeCode for micro:bit to write program, what

you will have to do to download the program to your Micro: Bit main board V2 is merely clicking the 'Download' button, then all is done.

If you are writing programs through the website, following these steps:

Click the 'Download' in the editor to download a "hex" file, which is a compact program format that the Micro: Bit main board can read. Once the hexadecimal file is downloaded, copy it to your board V2 just like the process that you copy the file to the USB driver. If you are running Windows system, you can also right-click and select 'Send to \rightarrow Microbit (E) 'to copy the hex file to the Micro: Bit main board V2



You can also directly drag the "hex" file onto the MICROBIT (E) disk.

File Home Share View	?
\leftarrow \rightarrow \checkmark \bigstar This PC \Rightarrow Downloads \checkmark \eth Search Downloads ,	Q
Desktop * Name Date modified Type Size	
Downloads microbit-heartbeat .hex 2020/7/15 16:57 HEX File 63 Pictures	1 KB
This PC MICROBIT (E)	
> Pretwork + Copy to MICROBIT (E:)	
1 item 1 item selected 630 KB	>

🖊 🛃 📙 🖛 Downloads				_	\times
File Home Share	View				~ 🕐
← → × ↑ 🕇 > This	PC > Downloads ~ 🗸	Sear	ch Dowr	nloads	Q,
📌 Quick access 📃 Desktop 🛷	microbit-heartbeat .hex				
➡ Downloads	■ 38% complete	-		×	
📄 Pictures 🛛 🖈 💻 This PC	38% complete		п	×	
MICROBIT (E:)	✓ More details				
Vetwork					
1 item 1 item selected 630) KB				; []

During the process of copying the downloaded hex file to the Micro: Bit main board V2, the yellow signal light on the back side of the board flashes. When the copy is completed, the yellow signal light will stop flashing and remain on.

Step 4: run the program

After the program is uploaded to the Micro: Bit main board V2, you could still power it via the USB cable or change to via an external power. The 5×5 LED dot matrix on the board displays the heartbeat pattern.



micro USB cable external power3V

Step 5other programming languages

This chapter has described how to use the Micro: Bit main board V2.

But except for the Makecode graphical programming introduced you can also write Micro: Bit programs in other

languages. Go to the link: https://microbit.org/code/ to know about other programming languages , or view the link: https://microbit.org/projects/, to find something you want to have a go.

5.2 5.2 Makecode

Browse https://makecode.microbit.org/ and enter Makecode online editor or open the APP MakeCode for micro:bit of Windows 10.



Click"New Project", and input"heartbeat"then enter Makecode editor, as shown below:

	Graph	nical and text			Setting	J	
🖸 micro:bit 🛛 🖀 Home	< 🖆 Blocks	JavaScript	~)	8	٠		Microsoft
C C C C C C C C C C C C C C	Search Q Blocks Basic O Input O Led Led Led C Loops C Loops C Loops C Logic E Variables	on start	Code e	editin	ig area		· · · · · · · · · · · · · · · · · · ·
Download code	Advanced		· ·	•	· ·	-	n n n n
초 Download 🛛 🚥	heartbeat Program	Save	j.	U	Indo	<mark>יי רי</mark> יי	+" zoom i -" zoom o

There are block"on start"and"forever"in the code editing area.

When the power is plugged or reset, "on start" means that blocks in the code are only executed once, "forever" implies that code will run cyclically.

5.3 5.3. Quick Download

As mentioned before, if your computer is Windows 10 and you have downloaded the APP MakeCode for micro:bit to write programs, the program written can be quickly downloaded to the Micro: Bit main board V2 by selecting 'Download'.

While it is a little more trickier if you are using a browser to enter makecode. However, if you use Google Chrome, suitable for LinuxmacOS and Windows 10, the process can be quicker too.

We use the webUSB function of Chrome to allow the internet page to access the hardware device connected USB.

You could refer to the following steps to connect and pair devices.

Pairing device

Connect micro:bit to your computer by USB cable. Click"..."beside"Download"and click"Pair device".

💿 micro:bit 🛛 🖀 Home	< Blocks	JavaScript	*	?	٠		Microsoft
	Search Q	on start	, fo	rever			
	Basic			show icon	·		
	 Input 						
	🖉 😡 Music		1	show icon			
00000	C Led						
0 1 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	I Radio						
🔳 C 🔅 🔹 🕮	C Loops						
	🔀 Logic						
	Variables						
	Math						
0 0 0 0 0	Advagad						
•	Pair device						
_) O { _ 4	Download to micro:bit						
🕹 Download	heartbeat	BO			- ξ]	ς Γ	° • •

Then click another"Pair device" as shown below.



Then select 'BBC micro:bit CMSIS-DPA' and click "Connect". If 'BBC micro:bit CMSIS-DPA''does not show up for selection, please refer to https://makecode.microbit.org/device/usb/webusb/troubleshoot

We also provide **7. Troubleshooting-WebUSB** in the resource link.

What's more, if you don't know how to update the firmware of micro:bit, refer to the link: https://microbit.org/guide/firmware/ or browse folder 4. How to Update the Firmware we provide.

⊖micro:bit	makecode.microbit.org wants to connect	E	N	/licro	soft
	"BBC micro:bit CMSIS-DAP"				
	Onnect Cancel	+			
🛓 Downl	oad heartbeat	n c	2	•	•

Then click"Download". The program is directly downloaded to Micro: Bit main board V2 and the sentence "Download completed!" appears.

💿 micro:bit 🖀 Home 🔫	Blocks	JavaSci	ript 🗸	00	- Mic	rosoft
	Search Q	on start	forever		4 4 4	
\sim	Basic		show i	con 🗰 🗸		
	 Input 			(1111)		
	O Music		show i	.con 🚼 🔻		
	C Led					
0 1 2 3V OND	al Radio					
■ C A + S	C Loops					
	C Logic					
	Uariables					
	Hath					
	✔ Advanced					
*, F 7 ()` ^	Download	d completed!			1. J	
- Download	heartbeat	B 0	<u> </u>	ି { ୮	e ا	•

5.4 5.4 Resources and test code

Tools ,test code and other resources can be downloaded via the link https://fs.keyestudio.com/KS4020-4021

Download and unzip the file, you will see a file clip named KS4020KS4021 Keyestudio EASY PLUG Super Starter Kit For BBC microbit STEM EDU-, and it contains following files:

- 퉬 1. About Keyestudio
- 퉬 2. Project Code
- 퉬 3. Tutorial
- 퉬 4. How to Update the Firmware
- 퉬 5. Microbit Driver Installation
- 6. Troubleshooting-MAINTENANCE Mode
- 퉬 7. Troubleshooting-WebUSB
- 퉬 8. Cool Term Download

5.5 5.5 Input test code

We provide hexadecimal code files (project files) for each project. The file contains all the contents of the project and can be imported directly, or you can manually drag the code blocks to complete the program for each project. For simple projects, dragging a block of code to complete the program is recommended. For complex projects, it is recommended to conduct the program by importing the hexadecimal code file we provide.

Let's take the "Heatbeat" project as an example to show how to load the code.

Open the Web version of Makecode or the Windows 10 App version of Makecode.



Open .mkcd or .hex file	0
Select a .mkcd or .hex file to open.	
Choose File No file chosen	
You can import files by dragging and dropping them anywhere in the editor!	
	Go ahead! 🗸

Select" ../Makecode Code/Project 1_ Heart beat/Project 1_ Heart beat.hex" ;

Then click "Go ahead".



Open .mkcd or .hex file	0
Select a .mkcd or .hex file to open.	
Choose File Project 1_ Heart beat.hex	
You can import files by dragging and dropping them anywhere in the editor!	1
Go ahead!	~

In addition to importing the test code file provided into the Makecode compiler above, you can also drag the the test code file provided into the code editing area of the Makecode compiler, as shown in the figure below:



After a few seconds, it is done.

🗂 micro:bit 🛛 🖀 Home	4		È Blocks		, s	lavaSo	cript	*		?	٠		M	licros	oft
		Search	Q	*											
		Basic			-				fores	PP					
	-	 Input 			on st	tart									
· D	7	O Music							sho	w icon					
		💽 Led							sho	w icon	w	-			
0 1 1 2 3V OND		al Radio													-
		C Loops													+
	<	X Logic													+
		🔳 Variab	les												+
e the state	2	📰 Math													+
	2	✔ Advan	ced												+
		-													+
															+
							-								÷
- Download	C	Heartbeat			8	0					٢	b (٩	•	Ð

Note: if your computer system is Windows7 or 8 instead of Windows 10, the pairing cannot be done via Google Chrome. Therefore, digital signal or analog signal of sensors and modules cannot be shown on the serial port simulator.

However, you need to read the corresponding digital signal or analog signal. So what can we do? You can use the CoolTerm software to read the serial port data of the micro:bit. Next chapter is about how to install CoolTerm.

5.6 5.6 CoolTerm Installation

CoolTerm program is used to read the data on serial port.

Download CoolTerm program:

https://freeware.the-meiers.org/

- 1. After the download, we need to install CoolTerm program file, below is Window system taken as an example.
- 2. Choose"win"to download the zip file of CoolTerm
- 3. Unzip file and open it. (also suitable for Mac and Linux system)

CoolTerm			
GoolTerm Libs	2020/4/21 11:20	File folder	
CoolTerm Resources	2020/4/21 11:20	File folder	
🐗 CoolTerm.exe	2019/5/17 22:56	Application	5,314 KB
🖄 msvcp120.dll	2019/4/3 14:33	Application extension	645 KB
🗟 msvcp140.dll	2019/4/3 14:33	Application extension	625 KB
🚳 msvcr120.dll	2019/4/3 14:33	Application extension	941 KB
ReadMe.txt	2019/5/18 20:35	Text Document	31 KB
🚳 vccorlib140.dll	2019/4/3 14:33	Application extension	387 KB
🗟 vcruntime140.dll	2019/4/3 14:33	Application extension	88 KB
Windows System Requirements.txt	2018/1/7 14:29	Text Document	1 KB
XojoGUIFramework64.dll	2019/4/3 14:33	Application extension	30,801 KB

Double-click ⁴/₋ CoolTerm.exe</sup>.



The functions of each button on the Toolbar are listed below: http://wiki.keyestudio.com/index.php/File:IDE.png



New	Opens up a new Terminal	
Open	Opens a saved Connection	
Save	Saves the current Connection to disk	
Connect	Opens the Serial Connection	
Disconnect	Closes the Serial Connection	
Clear Data	Clears the Received Data	
Options	Opens the Connection Options Dialog	
HEX View Hex	Displays the Terminal Data in Hexadecimal Format	
? Help	Displays the Help Window	
CHAPTER

SIX

6.PROJECTS

(Note: project 1 to 12 will be conducted with the built-in sensors and LED dot matrix of the Micro:bit main board V2)

6.1 Project 1: Heartbeat



1.Project Description

This experiment can be conducted with a micro:bit V2 main board, a micro USB cable and a computer.

The micro:bit will display a big heart-shaped image then a smaller one.

That is so-called a heartbeat image.

2.Components Needed:

- Micro:bit main board V2 *1
- Micro USB cable*1

3.Test Code:

Attach the Micro:bit main board V2 to your computer via the Micro USB cable and begin editing.



Firstly, click"basic"module and find and drag the block "show icon """ to module "forever";





Secondly, click"basic"module again and find and drag the block "show icon """ to module "forever" and click the little triangle to select "show icon """;



Thirdly, click"basic"module and find and drag the block" littler triangle to select 500;

Complete Program



Note: the "on start" means that blocks in the code are only executed once, "forever" implies that code will run cyclically.

Click "JS JavaScript", you will find the corresponding programming languages.

	Blocks		JavaScript	~	?	٠	Hicrosoft
Search	Q	1	basic.fore	ver(functi	lon on	_foreve	er() {
Basic		2	basic.	showIcon(1	conNar ConNar	nes.Hea nes Sma	art) allHeart)
O Input		4	<pre>})</pre>	5110W10011(1	connu		iincur cy
• mpar		5					
Music							

Click the little triangle"of JS JavaScript"to choose"Python", you will find the corresponding Python programming languages.

•	🔹 Blocks		🕏 Python	~	8	٠	Hicrosoft
Search	Q	1	def on_for	ever():	TeenNe		
Basic		2	basic. basic.	<pre>show_icon() show_icon()</pre>	I conNa I conNa	ames.Ht ames.SM	ART) ALL_HEART)
 Input 		4	basic.fore	ver(on_for	ever)		
Music		5					

4.Test Results:

Upload test code to micro:bit V2 and keep the computer and micro:bit board connected, Then the LED dot matrix

shows pattern" "and ""alternatively.

(Please refer to chapter 5.3 to know how to download test code quickly.)

If the downloading is not smooth, please remove the micro USB from the main board and then reconnect them and reopen Makecode to try again.

6.2 Project 2: Light Up A Single LED



1.Project Description:

The LED dot matrix consists of 25 LEDs arranged in a 5 by 5 square. In order to locate these LEDs quickly, as the figure shown below, we can regard this matrix as a coordinate system and create two aces by marking those in rows from 0 to 4 from top to bottom, and the ones in columns from 0 to 4 from the left to the right.

Therefore, the LED sat in the second of the first line is (1,0) and the LED positioned in the fifth of the fourth column is (3,4) and others likewise.



2.Components Needed:

- Micro:bit main board V2 *1
- Micro USB cable*1

3.Test Code:

Attach the Micro:bit main board V2 to your computer via the Micro USB cable and begin editing.

Firstly, click"Led"module and then the"more"module to find and drag the block "led enable false " to block" on start"; click the little triangle of "led enable false " to select" true";



Secondly, click"Led"module and to find and drag the block "toggle x 0 y 0" to block "forever" and alter "x0" to"x1";



Thirdly, click"Basic"module to find and drag the block"pause(ms)100"to"forever" block and set pause to 500;





Fifthly, click"Led"module to find and drag the block"plot x 0 y 0"to "forever" block and change the "x 0 y 0" to "x 3 y 4";



Sixthly, copy the block "pause(ms)500" and place it into forever" block;



Lastly, click"Led"module to find and drag the block"unplot x 0 y 0"to "forever"block and change"x 0 y 0"to"x 3 y 4";and copy and place the block"pause(ms)500"to block"forever";

Complete Program



Click "JS JavaScript", you will find the corresponding programming languages.

	ŧ	Blocks	JavaScript 🗸	•	٠	Microsoft
Search C	Q	1 2 3 4 5 6 7 8 9 10 11	<pre>led.enable(true) basic.forever(function () { led.toggle(1, 0) basic.pause(500) led.toggle(1, 0) basic.pause(500) led.plot(3, 4) basic.pause(500) led.unplot(3, 4) basic.pause(500) })</pre>			
C Loops		12				

Click the little triangle" of JS JavaScript" to choose "Python", you will find the corresponding Python programming languages.

-	ŧ	Blocks	Python	?	٠	Hicrosoft
Search	Q	1	led.enable(True)			
-		2				
Basic		3	<pre>def on_forever():</pre>			
		4	<pre>led.toggle(1, 0)</pre>			
 Input 		5	<pre>basic.pause(500)</pre>			
A Music		6	<pre>led.toggle(1, 0)</pre>			
WIGSIC		7	<pre>basic.pause(500)</pre>			
C Led		8	<pre>led.plot(3, 4)</pre>			
		9	<pre>basic.pause(500)</pre>			
I Radio		10	<pre>led.unplot(3, 4)</pre>			
		11	basic.pause(500)			
C Loops		12	<pre>basic.forever(on_forever)</pre>			
🔀 Logic		13	/			

Uploading test code to micro:bit V2 and power on it via the USB cable. The LED at (1,0) flashes for 0.5s and the one at (3,4) flashes for 0.5s

6.3 Project 3: LED Dot Matrix



1.Project Description:

Dot matrices are very commonplace in daily life. They are founded in LED advertisement screens, elevator floor displays, bus stops and so on.

The LED dot matrix of micro: bit V2 contains 25 LEDs in a grid. Previously, we have succeeded in controlling a certain LED on and off by integrating its position value into the test code. By the same theory, we can turn on many LEDs at the same time to showcase patterns, digits and characters.

2.Components Needed:

- Micro:bit main board V2 *1
- Micro USB cable*1

3.Test Code 1

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor.

Enter"Led" \rightarrow "more" \rightarrow "led enable false"



Click the drop-down triangle button to select"true"

Combine it with "on start" block

Click"Led"to move"plot x 0 y 0"into"forever"then replicate"plot x 0 y 0"for 8 times, respectively set to"x 2"y 0","x 2"y 1","x 2"y 2","x 2"y 3","x 2"y 4","x 1"y 3""x 0"y 2","x 3"y 3","x 4"y 2".



Complete Program



Select"JavaScript" and "Python" to switch into JavaScript and Python language code:

;	t	Blocks	JavaScript 🗸	?	٠	Hicrosoft
Search	Q	1	<pre>led.enable(true)</pre>			
Decio		2	<pre>basic.forever(function () { led plot(2, 0) </pre>			
Basic		3	led $plot(2, 0)$			
 Input 		5	led.plot(2, 1)			
		6	led.plot(2, 3)			
WUSIC		7	<pre>led.plot(2, 4)</pre>			
C Led		8	<pre>led.plot(1, 3)</pre>			
J Padio		9	<pre>led.plot(0, 2)</pre>			
.III Raulo		10	led.plot(3, 3)			
C Loops		11	led.plot(4, 2)			
		12	})			
Logic		15				
	*	Blocks	Python	?	٠	Microsoft
Search	(t Q	Blocks 1	<pre>Python led.enable(True)</pre>	8	٠	Microsoft
Search	± م	Blocks 1 2	<pre>Python led.enable(True)</pre>	8	•	- Microsoft
Search Basic	د م	Blocks 1 2 3	<pre>Python led.enable(True) def on_forever(): led_rlet(20)</pre>	?	•	Microsoft
Search Basic	Q.	Blocks	<pre> Python led.enable(True) def on_forever(): led.plot(2, 0) lod_plot(2, 1) </pre>	8	•	- Microsoft
Search Basic Input	Q	Blocks 1 2 3 4 5 6	<pre>Python led.enable(True) def on_forever(): led.plot(2, 0) led.plot(2, 1) led.plot(2, 2)</pre>	?	•	Microsoft
Search Basic O Input O Music	Q	Blocks 1 2 3 4 5 6 7	<pre>Python led.enable(True) def on_forever(): led.plot(2, 0) led.plot(2, 1) led.plot(2, 2) led.plot(2, 3)</pre>	8	•	- Microsoft
Search Basic O Input O Led	Q	Blocks 1 2 3 4 5 6 7 8	<pre>Python led.enable(True) def on_forever(): led.plot(2, 0) led.plot(2, 1) led.plot(2, 2) led.plot(2, 3) led.plot(2, 4)</pre>	•	•	Microsoft
Search Basic Input Music Led	Q	Blocks 1 2 3 4 5 6 7 8 9	<pre> Python led.enable(True) def on_forever(): led.plot(2, 0) led.plot(2, 1) led.plot(2, 2) led.plot(2, 3) led.plot(2, 4) led.plot(1, 3)</pre>	8	•	Microsoft
Search Basic Diput Music Cultation Radio	Q	Blocks 1 2 3 4 5 6 7 8 9 10	<pre>Python led.enable(True) def on_forever(): led.plot(2, 0) led.plot(2, 1) led.plot(2, 2) led.plot(2, 3) led.plot(2, 4) led.plot(1, 3) led.plot(0, 2)</pre>	3	•	Microsoft
Search Basic O Input O Led I Radio C Loops	Q	Blocks 1 2 3 4 5 6 7 8 9 10 11	<pre> Python led.enable(True) def on_forever(): led.plot(2, 0) led.plot(2, 1) led.plot(2, 2) led.plot(2, 3) led.plot(2, 4) led.plot(1, 3) led.plot(0, 2) led.plot(3, 3) led.plot(3, 3) </pre>	•	•	Microsoft
Search Basic Dinput Search Basic Input Search Led C Led C Loops	Q	Blocks 1 2 3 4 5 6 7 8 9 10 11 12 12	<pre> Python led.enable(True) def on_forever(): led.plot(2, 0) led.plot(2, 1) led.plot(2, 2) led.plot(2, 3) led.plot(2, 4) led.plot(1, 3) led.plot(0, 2) led.plot(3, 3) led.plot(4, 2) </pre>	3	•	Microsoft
Search Basic Difference D	Q	Blocks 1 2 3 4 5 6 7 8 9 10 11 12 13 14	<pre>Python led.enable(True) def on_forever(): led.plot(2, 0) led.plot(2, 1) led.plot(2, 2) led.plot(2, 3) led.plot(2, 4) led.plot(1, 3) led.plot(0, 2) led.plot(3, 3) led.plot(4, 2) basic.forever(on_forever)</pre>	3	٥	Microsoft



Upload code 1, we will see the

10

5.Test Code 2

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor.

Enter"Basic"→"show number 0"block,

Duplicate it for 4 times, then separately set to "show number 1", "show number 2", "show number 3", "show number 4", "show number 5".

on start	
show number 1	
show number 2	
show number 3	
show number 4	
show number 5	
	Γ

Click"Basic" \rightarrow "show leds", then put it into "forever"blocktick blue boxes to light LED and generate" \downarrow "pattern.



Move out the block"show string" from"Basic"block, and leave it beneath the"show leds" block



Choose "show icon" from "Basic" block, and leave it beneath the block "show string "Hello!" block



A. Enter"Basic"→"show arrow North";

B. Leave it into "forever" block replicate "show arrow North" for 3 times respectively set to "North East", "South East", "South West", "North West".



Click"Basic"to get block"clear screen"then remain it below the block "show arrow North West"

forever
show leds
show string "Hello!"
show icon 🔹 👻
show arrow North East -
show arrow South East -
show arrow South West -
show arrow North West 🔻
clear screen

Drag"pause (ms) 100"block from"Basic"block and set to 500ms, then leave it below"clear screen"block.



Complete Program:



Select"JavaScript" and "Python" to switch into JavaScript and Python language code:

	Blocks	JavaScript 🗸 🧐 😵 📑 Microsoft
Search Q Search Q Search Q Search Q Music	1 2 3 4 5 6 7	<pre>basic.showNumber(1) basic.showNumber(2) basic.showNumber(3) basic.showNumber(4) basic.showNumber(5) basic.forever(function () { basic.showLeds(` </pre>
 Led Radio Loops Logic 	8 9 10 11 12 13	· · # · · · · # · · # · # · # · # # # · · · # · · `)
Variables	14 15 16 17	<pre>basic.showString("Hello!") basic.showIcon(IconNames.Heart) basic.showArrow(ArrowNames.NorthEast) basic.showArrow(ArrowNames.SouthEast)</pre>
✓ Advanced	18 19 20 21 22 23	<pre>basic.showArrow(ArrowNames.SouthWest) basic.showArrow(ArrowNames.NorthWest) basic.clearScreen() basic.pause(500) })</pre>

	Blocks	🔮 Python 🗸 🚽 😨 🏟 💾 Microsoft
Search Q	1	<pre>basic.show_number(1)</pre>
	2	<pre>basic.show_number(2)</pre>
Basic	3	basic.show_number(3)
O Input	4	basic.snow_number(4)
	5	Dasic.snow_number(5)
R Music	7	def on forever():
Led	8	basic.show leds("""
-	9	#
I Radio	10	#
C Loops	11	# . # . #
	12	. # # # .
C Logic	13	#
Variables	14	having show string("uslls!")
	15	basic.snow_string(HellO!)
Math	17	basic show arrow(ArrowNames NORTH EAST)
	18	basic.show_arrow(ArrowNames.SOUTH_EAST)
✓ Advanced	19	basic.show arrow(ArrowNames.SOUTH WEST)
	20	<pre>basic.show_arrow(ArrowNames.NORTH_WEST)</pre>
	21	<pre>basic.clear_screen()</pre>
	22	<pre>basic.pause(500)</pre>
	23	basic.forever(on_forever)
	24	

Upload code 2 and plug the micro:bit to a computer. The micro: bit starts showing number 1, 2, 3, 4,





patterns.

6.4 Project 4: Programmable Buttons



1.Project Description:

Buttons can be used to control circuits. In an integrated circuit with a button, the circuit is controlled by the button.

Micro: Bit main board V2 boasts three buttons, two programmable buttons(A and B), and the one on the other side is a reset button. By pressing the two buttons, three different signals can be output.

The micro:bit will show A, B and AB if you press button A, B and AB respectively.

Let's get started.

2.Components Needed:

- Micro:bit main board V2 *1
- Micro USB cable*1

3.Test Code 1

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor,

Delete"on start"and"forever"firstlythen click"Input"→"on button A pressed"

A. Click"Basic"→"show string";



B. Then place it into"on button A pressed"block, change "Hello!"into"A".

	on button A - pressed show string "A"
Copy code string	once, tap the drop-down button"A"to select"B"and modify
	on button B 💌 pressed
	show string "B"
character"A"into"B	
*****	******







Select"JavaScript" and "Python" to switch into JavaScript and Python language code:



Upload the test code 1 to micro:bit main board V2. Then the 5*5 LED dot matrix will show A, B and AB if button A and B pressed together.

5.Test Code 2

A. Click"Led" \rightarrow "more" \rightarrow "led enable false",



B. Put it into the block"on start"click drop-down triangle button to select"true"

A. Tap"Variables" \rightarrow "Make a Variable..." \rightarrow "New variable name"

B. Enter"item"in the dialog box and click"OK"then variable"item"is produced. And move"set item to 0"into"on

start"block

on start
led enable true -
set item V 0

A. Click "Input" \rightarrow "on button A pressed".
B. Go to "Variables" \rightarrow " change item by 1 "
on button A v pressed change item v by 5
C. Place it into"on button A pressed"and 1 is modified into 5.
<pre>************************************</pre>
Duplicate code string onceclick the drop-down button to select"B"then

A. Enter "Led" \rightarrow "plot bar graph of 0 up to 0"
B. Keep it into"forever"block

C. Go to "Variables" to move "item" into 0 boxchange 0 into 25.

forever			
plot bar graph	of	item	•
up to 25			
		+	

- A. Go to "Logic" to move out "if...true...then..." and "="blocks
- B. Keep"="into"true"box and set to ">"
- C. Select"item"in the"Variables" and lay it down at left box of ">"change 0 into 25
- D. Enter"Variables"to drag"set item to 0"block into"if...true..then...", alter 0 into 25.





B.">" is modified into "<" and 25 is changed into 0,



Complete Program



	Bloo	cks	JavaScript 🗸 🕜 😵 📑 Microsoft
Search Basic Input Search Basic Input Led C Led C Loops C Loops C Logic Math	Q	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19	<pre>input.onButtonPressed(Button.A, function () { item += 5 }) input.onButtonPressed(Button.B, function () { item += -5 }) led.enable(true) let item = 0 basic.forever(function () { led.plotBarGraph(item, 25) if (item > 25) { item = 25 } if (item < 0) { item = 0 } }</pre>
 Advanced 		20	3)

Select"JavaScript" and "Python" to switch into JavaScript and Python language code:



Uploading test code 2 to micro:bit main board V2. A row of lights are turned on when you press button A, B the LEDs turning red reduce.

6.5 Project 5: Temperature Detection



Project Description:

Actually, the micro:bit V2 is not equipped with a temperature sensor, but uses the built-in NFR52833 chip for temperature detection. Therefore, the detected temperature should be closer to the chip.

1.Components Needed:

- Micro:bit main board V2 *1
- Micro USB cable*

2.Test Code 1

Click"Advanced"→"Serial"→"serial redirect to USB"into"on start"



Go to"Serial"→"serial write value"x"=0"into"forever"

forever					
serial write value	"Te	mpera	ture ")=(0
	+	+	+	\pm	+

Click "Input" \rightarrow "temperature(°C)" into "into serial write value" x"=0 and change" 0" into "temperature"

forever								
serial write val	lue ("Te	empera	ature ") = (tempe	rature	≘ (°C)	
	+	+	+	+	+	+	+	+
te ste ste ste ste ste ste ste ste ste s	14 s14 s14 s14 s14 s14 s14 s14 s	1e ale ale ale ale ale ale					14 - 14 - 14 - 14 - 14	

Go to "Basic" \rightarrow "pause (ms) 100" into "forever" and set pause to 500

forever	+							
serial write val	lue ("Te	empera	ture ") = (tempe	rature	e (°C)	
pause (ms) 500	•	+	+	+	+	+	+	-
	-							
					14 214 214 214 214 214 214			

Complete Program

on start	+							
serial redirect	to USB	+						
	+	-						
forever	+							
serial write val	Lue ("Te	empera	ture ")=	tempe	ratur	e (°C)
pause (ms) 500	•	+	+	+	+	+	+	+
	-							



Select"JavaScript" and "Python" to switch into JavaScript and Python language code:

	∎ B	locks	JavaScript	$\overline{\mathbf{v}}$		(?	٠	Hicrosoft
\$ Search	Q	1	serial.redire	ectTol	JSB()				
Basic		2	serial.w	r(fund riteVa	alue("Tempe	rature",	, in	put.te	emperature())
Input		4	<pre>basic.pau })</pre>	use(50	90)				
Music		6							

	⋭ B	locks	👻 Python 🗸 🖊 🥵 🚼 Microsoft
Search	Q	1	<pre>serial.redirect_to_usb()</pre>
Basic		3	<pre>def on_forever():</pre>
 Input 		4	<pre>serial.write_value("Temperature", input.temperature()) basic_pause(500)</pre>
🞧 Music		6	<pre>basic.forever(on_forever)</pre>
C Led		7	

Upload test code 1 to micro:bit V2, attach it to a computer and click"Show console Device". Then the data of temperature is displayed in the serial monitor page as shown below.





Only on Windows 10 can Google Chrome match with devices. If you use other Windows systems, the CoolTerm serial monitor is best choice for reading data.

Open CoolTerm software, click Options, select SerialPort, set COM port and baud rate to 115200 (after testing, the baud rate of USB SerialPort communication on Micro:bit V2 is 115200), click OK, and Connect.

Then the CoolTerm serial monitor shows the change of temperature value in the current environment, as shown in the figures below :

Untitled_0	Vindew Mala
New Open Save Connect	Disconnect Clear Data Options View Hex Help
Connection Options (Untit Serial Port Ierminal Receive Transmit	Serial Port Options Port: COM19
Miscellaneous	Data Bits: 8 Parity: none Stop Bits: 1
	Flow Control: CTS DTR XON
	Software Supported Flow Control
	Initial Line States when Port opens:

✓ Untitled_0		Π -	
File Edit Connection View \	Window Help	<u> </u>	
New Open Save Connect Connection Options (Untit	Disconnect Clear Data	Options View	Hex Help
Serial Port Terminal Receive Transmit Miscellaneous	Serial Port OptionsPort:COM16Baudrate:9600Data Bits:600Parity:1200Parity:1800Stop Bits:3600Flow Control:72009600144001920028800Software Supp38400Software Supp38400Software Supp230400Initial Line StatesCustom● DTR OnO DTR Of● RTS OnRTS Of	<pre> </pre>	
	Re-Scan Ser Ca	ial Ports	<u>}</u>


✓ Untitled_0 *		—	x I
File Edit Connection View Window Help			
New Open Save Connect Disconnect	ear Data	HEX View Hex	? Help
Temperature:23			^
Temperature:23			
Temperature:24			
Temperature:25			
Temperature:25			
Temperature:27			
Temperature:28			
Temperature:29			
Temperature:29			
			~
			-
COM16 / 115200 8-N-1	🔘 TX 🛛 🕤 RTS	5 🕒 DTR	DCD
Connected 00:00:09	🔴 RX 🛛 🕚 CTS	🕒 DSR	🕘 RI

4.Test Code 2

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor,

A. Go to "Led" \rightarrow "more" \rightarrow "led enable false" block,



B. Keep it into the "on start" blocktap the triangle button to select "true".

Tap"Logic"and drag"if...then...else"into"forever"block; and then drag "=" into "true"



Enter"Input"to move"temperature(°C)"into the left side of "="; click the little triangle of "="to choose "",and change the "0"to "35"



Click"Basic"to find out block"show icon"and move it into"then"; copy and place the block"show icon"to "else" and





Complete Program

on start	÷							
serial redirect	to USB	+						
	+							
forever	+							
serial write val	Lue (T	emper	ature	")=	tem	perati	ure (°C)
pause (ms) 500	•	÷	+	+	÷+	+	4	1





will appear.



temperature is equivalent to or greater than 35°C, the image



6.6 Project 6: Geomagnetic Sensor

1.Project Description:

This project aims to explain the use of the micro: bit geomagnetic sensor, which can not only detect the strength of the geomagnetic field, but also be used as a compass to find bearings. It is also an important part of the navigation attitude reference system (AHRS).

Micro: Bit main board V2 uses LSM303AGR geomagnetic sensor, and the dynamic range of magnetic field is ± 50 gauss. In the board, the magnetometer module is used in both magnetic detection and compass. In this experiment, the compass will be introduced first, and then the original data of the magnetometer will be checked.

The main component of a common compass is a magnetic needle, which can be rotated by the geomagnetic field and point toward the geomagnetic North Pole (which is near the geographic South Pole) to determine direction.

2.Components Needed:

- Micro:bit main board V2 *1
- Micro USB cable*1

3.Test Code 1

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor.

- A. Click"Input" \rightarrow "more" \rightarrow "calibrate compass"
- B. Lay down it into block"on start".



- A. Go to "Input" \rightarrow "on button A pressed".
- B. Enter"Basic"→"show number", put it into"on button A pressed"block;
- C. Tap"Input" \rightarrow "compass heading(°C)" and place it into "show number"

on button	Α 🔻	pressed	+	
show num	ber d	compass he	eading	(°)
			+	+
*****	******	*****	*****	******

Complete Program	
on start calibrate compass	 "on start": command block only runs once to start program. (2) Calibrate compass (3) Press button A on Micro:bit main board
show number compass heading (°)	④ Dot matrix shows the direction of compass heading

; (t	Blocks	JavaScript 🗸 😯 🏟 Microsoft
Search Basic	Q	1 2 3 4	<pre>input.onButtonPressed(Button.A, function () { basic.showNumber(input.compassHeading()) }) input.calibrateCompass()</pre>
 Input 		5	
:	t	Blocks	🕈 Python 🗸 🗸 😯 🎝 Microsoft
Search Basic	t Q	Blocks	<pre> Python P</pre>

4.Test Results 1

Upload test code to micro:bit V2, plug it to a power, and press the button A. The board will send request to calibrate compass and show"TILT TO FILL SCREEN"; then enter the calibration page.

Rotate the board until all 25 LEDs are fully on, as shown below.





After that, a smile pattern **appears**, which implies that the calibration is done. When the calibration process is

completed, the reading value will be displayed if you press the button A.

And the direction north, east, south and west correspond to $0^\circ,\,90^\circ,\,180^\circ$ and $270^\circ.$

5.Test Code 2



This module can keep readings and determine direction



For the above picture, the arrow pointing to the upper left when the value ranges from 292.5 to 337.5. 0.5 can't be input in the code, thereby, the values we get are 293 and 338.

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor,

- 1. Enter"Input" \rightarrow "more" \rightarrow "calibrate compass"
- 2. Move"calibrate compass"into"on start"



- A. Click"Variables"→"Make a Variable…"→"New variable name"
- B. Input"x"in the blank box and click"OK", and the variable "x" is generated.
- C. Drag out"set x to"into"forever"block



A. Go to "Input" \rightarrow "compass heading(°C)", and keep it into "0" box

1	oreve	r					+
	set	x •	to	compass	head:	ing (°	")
				+	+	+	+

Tap"Logic" – "if... then... else", leave it below block "sex x to compass heading", then click icon for 6 times.

- A. Place"and"into"true"block
- B. Then move"="block to the left box of "and"
- C. Click"Variables"to drag"x"to the left "0"box, change 0 into 293 and set to "";
- D. Then copy"x293" once and leave it to the right "0" box and set to"x<338"







6 times.

B. Separately leave them into the blank boxes behind "else if".

C. Set to"x23 and x<68","x68 and x<113 ","x113 and x<158 ","x158 and x<203 ","x203 and x<248 ","x248 and x<293 "respectively.

D. Then copy "show leds" for 7 times and keep them below the "else if.....then" block respectively.



Complete Program



:	Blocks	JavaScript 🗸 🧭 😯 Microsoft
Search Q	1	<pre>let x = 0 input calibrateCompass()</pre>
	2	basic.forever(function () {
Basic	4	<pre>x = input.compassHeading()</pre>
	5	if (x >= 293 && x < 338) {
U mput	6	basic.showLeds(`
O Music	7	
	8	##
C Led	10	
J. Dedie	11	#
Radio	12	`)
C Loops	13	} else if (x >= 23 && x < 68) {
	14	basic.showLeds(
C Logic	16	# #
🚍 Mariahlar	17	# . #
variables	18	# .
Hath	19	#
	20) $(x = 60.88 \times (112))$
	21	basic.showleds(`
	23	#
	24	. #
	25	# # # #
	26	. #
	27	
	28) also if $(y > 442, 89, y < 459)$ (
	29	f = 115 and X < 158 f
	31	#
	32	· · · # ·
	33	# . #
	34	# #
	35	# # #
	36	

```
37
        } else if (x >= 158 && x < 203) {</pre>
38
            basic.showLeds(`
39
                 . . # . .
40
                 . . # . .
41
                 # . # . #
42
                 . # # # .
43
                 . . # . .
                 `)
44
        } else if (x >= 203 && x < 248) {
45
46
            basic.showLeds(`
47
                 # . . . .
48
                 . # . . .
49
                 . . # . #
                 . . . # #
50
51
                 . . # # #
                 `)
52
53
        } else if (x >= 248 && x < 293) {
54
            basic.showLeds(`
                 . . # . .
55
56
                 . . . # .
                 # # # # #
57
58
                 . . . # .
59
                 . . # . .
                 `)
60
61
        } else {
62
            basic.showLeds(`
63
                 . . # . .
                 . # # # .
64
                 # . # . #
65
66
                 . . # . .
67
                 . . # . .
68
                 `)
69
        }
70
    })
71
```

Search 0 1 x = 0	
Sedicit 2 input.calibrate_compass()	
Basic 3 4 def on_forever():	
<pre> 5 global x 6 x = input.compass_heading() </pre>	
<pre></pre>	
C Led 10 # #	
Radio 12 . # 13 #	
C Loops 14 """) 15 elif x >= 23 and x < 68:	
Cogic 16 basic.show_leds(""" 17 # # #	
Variables 18 # # 19 # . #	
20 # . Math 21 # 23 #	
✓ Advanced 23 elif x >= 68 and x < 113: 24 basic.show leds("""	
25 # 26 #	
27 # # # # # 28 . #	
29 # 30 """)	
<pre>31 elif x >= 113 and x < 158: 32 basic.show_leds("""</pre>	
33 # 34 # .	
36 # # # 37 # # #	

39	elif x >= 158 and x < 203:
40	<pre>basic.show_leds("""</pre>
41	#
42	#
43	# . # . #
44	. # # # .
45	#
46	""")
47	elif x >= 203 and x < 248:
48	<pre>basic.show_leds("""</pre>
49	#
50	. #
51	# . #
52	# #
53	# # #
54	""")
55	elif x >= 248 and x < 293:
56	<pre>basic.show_leds("""</pre>
57	#
58	# .
59	# # # # #
60	# .
61	#
62	""")
63	else:
64	<pre>basic.show_leds("""</pre>
65	#
66	. # # # .
67	# . # . #
68	#
69	#
70	""")
71	<pre>basic.forever(on_forever)</pre>
72	

6.Test Results 2

Upload code 2 and plug the micro:bit to a power. After calibrating and tilting the micro:bit V2, the LED dot matrix will display the direction signs.

COMPASS PINS PINS COMPASS PINS COMPASS COMPASS

6.7 Project 7: Accelerometer

1.Project Description:

The Micro: bit V2 has a built-in LSM303AGR gravity acceleration sensor, also known as accelerometer, with a resolution of 8/10/12 bits. The code section sets the range to 1g, 2g, 4g, and 8g.

We often use accelerometer to detect the status of machines.

In this project, we will introduce how to measure the position of the board with the accelerometer. And then have a look at the original three-axis data output by the accelerometer.

2.Components Needed:

- Micro:bit main board V2 *1
- Micro USB cable*1

3.Test Code 1

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor,

(1) A. Enter"Input" \rightarrow "on shake"



B. Click "Basic" \rightarrow "show number", place it into "on shake "block, then change 0 into 1.



separately click the triangle button to select"logo up","logo down","screen up", "screen down", "tilt left", "tilt right" and "free fall", then respectively change 1 into 2, 3, 4, 5, 6, 7, 8.

Complete Program



Search Q 1 input.onGesture(Gesture.FreeFall, function () { 2 basic.showNumber(8) 3 }) iiii Basic 4 input.onGesture(Gesture.LogoUp, function () { iput.onGesture(Gesture.TiltLeft, function () { 5 basic.showNumber(2) 6 }) 7 input.onGesture(Gesture.TiltLeft, function () { Imput.onGesture(Gesture.ScreenUp, function () { 9 }) Imput.onGesture(Gesture.ScreenUp, function () { 11 basic.showNumber(4) Imput.onGesture(Gesture.ScreenDown, function () { 12 }) Imput.onGesture(Gesture.ScreenDown, function () { basic.showNumber(5) Imput.onGesture(Gesture.ScreenDown, function () { basic.showNumber(1) Imput.onGesture(Gesture.Stake, function () { basic.showNumber(1) Imput.onGesture(Gesture.TiltRight, function () { basic.showNumber(7) Imput.onGesture(Gesture.LogoDown, function () { basic.showNumber(3) Imput.onGesture(Gesture.LogoDown, function () { basi	SearchQImage: BasicImage: BasicImage: Image: Im

8			ŧ	Blocks		Python	~		?	٠	Hicrosoft
	Search.		0	1	def or	_gesture_fr	ee_fall():				
	ocuroni		~	2	ba	asic.show_nu	mber(8)				(-11)
	Ba	sic		3 4	input.	on_gesture(Gesture.FREE_	FALL,	on_gest	cure_fre	e_tall)
				5	def or	_gesture_lo	go_up():				
		out		6	ba	asic.show_nu	mber(2)				
	О М	usic		7	input.	on_gesture(Gesture.LOGO_	_UP, on	_gestur	re_logo_	_up)
				8	def or	gostupo ti	1+ lof+().				
	💽 Le	d		10	ba	sic.show nu	mber(6)				
				11	input.	on_gesture(Gesture.TILT_	LEFT,	on_gest	ture_til	lt_left)
	II Ra	oid		12							
	CL	ops		13	def or	_gesture_sc	reen_up():				
	•			14	ba	asic.show_nu	mber(4)				
	X Lo	gic		15	input.	on_gesture(Gesture.Stkee	:N_UP,	on_gest	ture_scr	een_up)
	= va	riables		17	def or	_gesture_sc	reen_down():				
		Indules		18	ba	asic.show_nu	mber(5)				
	Ma	ath		19 20	input.	on_gesture(Gesture.SCREE	EN_DOWN	, on_ge	esture_s	screen_down)
				21	def or	_gesture_sh	ake():				
	🗸 🗸	lvanced		22	ba	asic.show_nu	mber(1)				
				23	input.	on_gesture(Gesture.SHAKE	E, on_g	esture	_shake)	
				24	def or	gesture ti	lt_right():				
				26	ba	sic.show nu	mber(7)				
				27	input.	on_gesture(Gesture.TILT_	RIGHT,	on_ges	sture_ti	ilt_right)
				28							
				29	def or	_gesture_lo	go_down():				
				30	ba	asic.show_nu	mber(3)				
				31	input.	on_gesture(Gesture.LOGO_	DOWN,	on_gest	ture_log	go_down)

4.Test Results 1:

Uploading the test code 1 to micro: bit V2 and powering it on via the USB cable. If we shake the micro: bit V2. the LED dot matrix will display "1".

When it is kept uprightits logo above the LED dot matrix, the number 2 will show.



When it is kept upside down(its logo below the LED dot matrix), it will show as below.



When it is placed still on the desk, showing its front side, the number 4 appears.



When it is placed still on the desk, showing its back side, the number 5 will exhibit.

When the board is tilted to the left, the LED dot matrix shows the number 6 as shown below.



When the board is tilted to the right, the LED dot matrix displays the number 7 as shown below



When the board is knocked to the floor, this process can be considered as a free fall and the LED dot matrix shows the number 8. (please note that this test is not recommended for it may damage the main board.)

5.Test Code 2

- A. Go to "Advanced" \rightarrow "Serial" \rightarrow "serial redirect to USB"
- B. Drag it into"on start"

on start serial redirec	t to USB			
*****	*****	********	*****	*****
A. Enter"Serial"→"seri	al write value x =	=0"		
B. Leave it into"forever"	'block			
forever serial write v	alue "x" =	= 0		
*****	*****	*********	******	*****
A. Click"Input"→"acce	leration(mg) x"			
B. Keep it into"0"box an	nd capitalize the"	ʻx"		
forever	19 - 19		+ +	
serial write v	alue "X" =	= accele	ration (mg) x •
*****	*******	*********	**********	*****
Go to"Basic" and move c	out"pause (ms) 10	00"below the	seri	al write
then set to 100ms.	at pause (iiis) 10		010011	
forever			+ •	
serial write v	alue <mark>"X"</mark> =	accele	ration (mg) x •
pause (ms) 10	10 -			



Replicate code string

keep them into"forever"blockseparately set the whole code string as follows:

forever									
serial write val	lue 🕛	x") =	acce	lerat	ion	(mg)	x •		
pause (ms) 100	•	+	+	+	+	+	+	+	
serial write val	lue 🕛	Y" =	acce	lerat	ion	(mg)	у 🕶		
pause (ms) 100	•	+	+	+	÷	+	+	+	
serial write val	ue 🕛	Z") =	acce	lerat	ion	(mg)	z 🔹		
pause (ms) 100	•	+	+	+	+	+	+	+	+
serial write val	lue 🕛	s") =	acce	lerat	ion	(mg)	strer	ngth 🔻	
pause (ms) 100	•							+	

Complete Program

<pre>serial redirect to USB forever serial write value `X` = acceleration (mg) x * pause (ms) 100 * serial write value `Y` = acceleration (mg) y * pause (ms) 100 * serial write value `2` = acceleration (mg) z * pause (ms) 100 * serial write value `5` = acceleration (mg) strength * pause (ms) 100 *</pre>	on start	
<pre>forever serial write value ** • acceleration (mg) ** pause (ms) 100 * serial write value ** • acceleration (mg) * pause (ms) 100 * serial write value ** • acceleration (mg) * pause (ms) 100 * serial write value ** • acceleration (mg) * pause (ms) 100 * serial write value ** • acceleration (mg) * pause (ms) 100 * serial write value ** • acceleration value on y axis Serial write value ** ** ** ** ** ** ** ** ** ** ** ** **</pre>	serial redirect to USB	
<pre>serial write value `X` = acceleration (mg) X * pause (ms) 100 * serial write value `Y` = acceleration (mg) Y * pause (ms) 100 * serial write value `Z` = acceleration (mg) Z * pause (ms) 100 * serial write value `S` = acceleration (mg) strength * pause (ms) 100 *</pre>	Fanavan	
<pre>serial write value `Y' = acceleration (mg) y * pause (ms) 100 * serial write value `Z' = acceleration (mg) z * pause (ms) 100 * serial write value `S' = acceleration (mg) strength * pause (ms) 100 *</pre> Serial write value `S' = acceleration (mg) strength * pause (ms) 100 * <pre> Serial write value `S'' = acceleration value on s axis</pre>	serial write value ('X') = acceleration (mg) x ♥)	"on start": command block runs once to start program.
serial write value $`Y' = acceleration (mg) y \\$ pause (ms) 100 \sim serial write value $`Z' = acceleration (mg) z \\$ pause (ms) 100 \sim serial write value $`S' = acceleration (mg) strength \\$ pause (ms) 100 \sim serial write value $S'' = acceleration value on z axis \\$ Serial write value $S'' = acceleration value on z axis \\$ Serial write value $S'' = acceleration value on z axis \\$ Serial write value $S'' = acceleration value on z axis \\$ Serial write value $S'' = acceleration value on z axis \\$ Serial write value $S'' = acceleration value on z axis \\$	pause (ms) 100 🔻	Serial redirects to USB
Serial write value "X"=acceleration value on x axis Serial write value "X"=acceleration value on y axis Serial write value "Y"=acceleration value on y axis Serial write value "Z"=acceleration value on z axis Serial write value "S"=acceleration value on z axis	serial write value [*] Y [*] = acceleration (mg) y ▼	The program under the block "forever" runs cyclically.
serial write value Z* = acceleration (mg) Z* pause (ms) 100 * serial write value S* = acceleration (mg) serial write value S* = acceleration value on z axis Serial write value S* = acceleration value on s axis	pause (ms) 100 🔻	Serial write value "X"=acceleration value on x axis
pause (ms) 100 • Serial write value "Z"=acceleration value on z axis Serial write value "Z"=acceleration value on z axis Serial write value "S"=acceleration value on s axis	serial write value [*] Z [*] = acceleration (mg) Z •	Serial write value "Y"=acceleration value on y axis
serial write value "S" = acceleration (mg) strength ▼ pause (ms) 100 ▼	pause (ms) 100 🔻	Serial write value "Z"=acceleration value on z axis
pause (ms) 100 -	serial write value <code>`S'</code> = <code>acceleration (mg) strength ▼</code>	Serial write value ``S"=acceleration value on s axis
	pause (ms) 100 🔻	

: (ŧ	Blocks	JavaScript 🗸 🚱 🏟 📑 Microsoft
Cooreb	0	1	serial.redirectToUSB()
Search	Q	2	<pre>basic.forever(function () {</pre>
Pagia		3	<pre>serial.writeValue("X", input.acceleration(Dimension.X))</pre>
Basic		4	basic.pause(100)
		5	<pre>serial.writeValue("Y", input.acceleration(Dimension.Y))</pre>
U input		6	basic.pause(100)
O Music		7	<pre>serial.writeValue("Z", input.acceleration(Dimension.Z))</pre>
VIUSIC		8	basic.pause(100)
		9	<pre>serial.writeValue("S", input.acceleration(Dimension.Strength))</pre>
Leu		10	basic.pause(100)
Radio		11	})
		12	

; (t 1	Blocks	🗣 Python 🗸 🥌 😯 🛃 Microsoft
Search	Q	1	<pre>serial.redirect_to_usb()</pre>
Basic		3	<pre>def on_forever(): serial.write_value("X", input.acceleration(Dimension.X))</pre>
 Input 		5 6	<pre>basic.pause(100) serial.write_value("Y", input.acceleration(Dimension.Y))</pre>
Music		7 8	<pre>basic.pause(100) serial.write_value("Z", input.acceleration(Dimension.Z))</pre>
Led		9 10	<pre>basic.pause(100) serial.write_value("S", input.acceleration(Dimension.STRENGTH))</pre>
I Radio		11 12	<pre>basic.pause(100) basic.forever(on_forever)</pre>
C Loops		13	

6.Test Results 2

Upload test code to micro:bit main board V2, power the main board via the USB cable, and click "Show console Device".



After referring to the MMA8653FC data manual and the hardware schematic diagram of the Micro: bit main board V2, the accelerometer coordinate of the Micro: bit V2 motherboard are shown in the figure below:



The following interface shows the decomposition value of acceleration in X axis, Y axis and Z axis respectively, as well as acceleration synthesis (acceleration synthesis of gravity and other external forces).



If you're running Windows 7 or 8 instead of Windows 10, via Google Chrome won't be able to match devices. You'll need to use the CoolTerm serial monitor software to read data.

You could open CoolTerm software, click Options, select SerialPort, set COM port and baud rate to 115200 (after testing, the baud rate of USB SerialPort communication on Micro: Bit main board V2 is 115200), click OK, and Connect. The CoolTerm serial monitor shows the data of X axis, Y axis and Z axis, as shown in the figures below :

✓ Untitled_0 *	—		×
File Edit Connection View Window Help			
Image: New Open Save Image: Save	HEX View He	ex Help	
S:922 X:-912 Y:864 Z:-620 S:1320 X:-280 Y:-676 Z:-296 S:1364 X:-180 Y:-836 Z:-4 S:878			^
X:-812 Y:-268 Z:-300 S:518 X:140 Y:-372 Z:1004 S:1108 X:-656 Y:-268 Z:-992 S:740 X:84 Y:-40			~
COM16 / 115200 -N-1	E ts 🕒 d t Stts 🍈 ds	f r 🍈 dci Sr 🍈 ri	D

6.8 Project 8: Light Detection



1.Project Description:

In this project, we focus on the light detection function of the Micro: Bit mainboard V2. It is achieved by the LED dot matrix. And it can be viewed as a photosensor.

2.Components Needed:

- Micro:bit main board V2 *1
- Micro USB cable*1

3.Test Code

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor,

(1)A. Enter"Advanced" \rightarrow "Serial" \rightarrow "serial redirect to USB";



B. Drag it into"on start"block.

(2) A. Go to "Serial" \rightarrow "serial write value x =0";



B. Move it into"forever"

1. A. Click"Input"→"acceleration(mg) x"

B. Put"acceleration(mg) x"in the"0"box and change "x"into"Light intensity".

f	orever	-							
	serial write val	lue (" Light	int	ensity	")=	ligh	nt lev	/el
		÷	+	+	+	+	+	+	+
***	****	****	*******	*****	******	*****	*****	*****	****

- 1. A. Click"Basic"→"pause (ms) 100";
- B. Lay it down into "forever" and set to 100ms.

forever	+							
serial write val	lue (Light	int	ensity	• =	lig	nt lev	vel
pause (ms) 100	•	+	+	+	+	+	+	+
	1							
****	****	*****	*****	*****	*****	*****	*****	****

Complete Program

on start	+	+	+	+	+	+	+	"on start": command block runs once to start program.
serial redirect t	o USB							Serial redirects to USB
forever								The program under the block "forever" runs cydically.
serial write valu	e <mark>'Li</mark>	ght i	ntens	ity"	= 1	light	level	Serial write value "Light intensity"
pause (ms) 100								Delay in 100ms



4.Test Results:

Upload the test code to micro:bit main board V2, power the board via the USB cable and click"Show console Device".



When the LED dot matrix is covered by hand, the light intensity showed is approximately 0; when the LED dot matrix is exposed to light, the light intensity displayed gets stronger with the light as shown below.

128	← Go back	Device 🔲 📥 🗠
		144,60
■ C ± +0 S	Light intensity: 144	0.00
III Show console Simulator		
III Show console Device		
* 20 C ^		
	49 Light intensity:0 Light intensity:23	
	Light intensity:47 Light intensity:51 Light intensity:57	
	Light intensity:70 Light intensity:89	
	Light intensity:109 Light intensity:128	
	Light intensity:144	· · · · · · · · · · · · · · · · · · ·

The 20 in the code is an arbitrary value of light intensity. If the current light level is less than or equal to 20, the moon will appear on the LED dot matrix. If it's bigger than 20, the sun will appear.

If you're running Windows 7 or 8 instead of Windows 10, via Google Chrome won't be able to match devices. You'll need to use the CoolTerm serial monitor software to read data.

You could open CoolTerm software, click Options, select SerialPort, set COM port and baud rate to 115200 (after testing, the baud rate of USB SerialPort communication on Micro: Bit main board V2 is 115200), click OK, and Connect. The CoolTerm serial monitor shows the value of light intensity, as shown in the figures below :

✓ Untitled_0 *	- 🗆 X
File Edit Connection View Window Help	
New Open Save Connect Disconnect	Data Options View Hex Help
Light intensity:31 Light intensity:30 Light intensity:24 Light intensity:23 Light intensity:23 Light intensity:24 Light intensity:24 Light intensity:24 Light intensity:25 Light intensity:29 Light intensity:78 Light intensity:147 Light intensity:171 Light intensity:198 Light intensity:20	
Light intensity:221 Light intensity:221	v
COM16 / 115200 8 -N-1 Connected 00:03:16	TX Image: RTS Image: DTR Image: DCD RX Image: CTS Image: DSR Image: RI

6.9 Project 9: Speaker



1.Project Description:

The Micro: bit main board V2 has an built-in speaker, which makes adding sound to the programs easier. We can program the speaker to air all kinds of tones .

2.Components Needed:

- Micro:bit main board V2 *1
- Micro USB cable*1

3.Test Code

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor,

(1) Enter"Basic" module to find "show icon" and drag it into "on start" block;




(2) Enter"Music" module to find and drug"play sound giggle until done" into"forever" block;

Enter"Basic"module to find and drug"pause(ms) 100"into"forever"block ;

Change 100 into 1000;

foreve						
play	sound	iggle	• un	til d	lone	
pause	e (ms) f	1000 💌				
	play so	und g:	iggle	• u	ntil	done
(3) Copy	pause (ms) 1	000 💌			

three times and place it into "forever" block ;

Click the little triangle to select "happy","hello","yawn";

forever			
play sound	giggle 🔻	until d	done
pause (ms)	1000 💌		
play sound	happy 🔻	until de	one
pause (ms)	1000 -		
play sound	hello 🔻	until de	one
pause (ms)	1000 🔻		
play sound	yawn 🔻 ı	until dou	ne
pause (ms)	1000 💌		
\sim			

Complete Program



Select"JavaScript" and "Python" to switch into JavaScript and Python language code:

* B	locks	JavaScript 🗸 🗲 😧 🏟 💾 Microsoft					
Search	λ 1	<pre>basic.showIcon(IconNames.EigthNote)</pre>					
	2	<pre>basic.forever(function () {</pre>					
Basic	3	<pre>soundExpression.giggle.playUntilDone()</pre>					
 Input 	4	basic.pause(1000)					
O Music	5	soundExpression.happy.playUntilDone()					
V Music	7	soundExpression ballo playUntilDone()					
C Led	8	<pre>basic.pause(1000)</pre>					
Radio	9	<pre>soundExpression.yawn.playUntilDone()</pre>					
	10	basic.pause(1000)					
C Loops	11	})					
🔀 Logic	12						
< * •	Blocks	🕈 Python 🗸 🧭 😨 🏶 Microsoft					
Search	Q 1	<pre>basic.show_icon(IconNames.EIGTH_NOTE)</pre>					
	2						
Basic	3	<pre>def on_forever():</pre>					
 Input 	4	<pre>soundExpression.giggle.play_until_done()</pre>					
O Music	5	basic.pause(1000)					
QP Music	6	soundExpression.nappy.play_until_done()					
C Led	/	soundExpression hello play until done()					
Radio	9	basic.pause(1000)					
	10	<pre>soundExpression.yawn.play until done()</pre>					
C Loops	11	basic.pause(1000)					
X Logic	12	<pre>basic.forever(on_forever)</pre>					
Variables	13						

4.Test Results:

Uploading the test code to micro:bit main board V2 and powering the board via the USB cable, the speaker utters sound and the LED dot matrix shows the logo of music.

6.10 Project 10: Touch-sensitive Logo



1.Project Description:

The Micro: Bit main board V2 is equipped with a golden touch-sensitive logo, which can act as an input component and function like an extra button.

It contains a capacitive touch sensor that senses small changes in the electric field when pressed (or touched), just like your phone or tablet screen do. When you press it, you can activate the program.

2.Components Needed:

- Micro:bit main board V2 *1
- Micro USB cable*1

3.Test Code

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor,

Delete block"on start"and"forever";

Enter"Input" module to find and drag" on logo pressed";

Click the little triangle to find "touched";



Enter module "Variables" -> choose "Make a Variable" -> input "start" -> click "OK"

The variable"start" is established;

Enter"Variables" module to find and drag "set start to 0" into "on logo touched" block;



Enter"Input"module →click "more"→ find and drag"running time(ms)" into the "0"of"set start to 0"block;



Enter"Input"module to find and drag"on logo pressed"→choose "released"→ establish variable "time"; Enter"Variables"module to find and drag "set time to 0"into "on logo pressed"block; Enter"Math"module to find and drag "0-0"into the "0"of"set start to 0"block;



Enter"Input" module \rightarrow "more" \rightarrow find and drag "running time(ms)" into"0" on the left side of "0-0"; Enter"Variables" module to find and drag "start" into "0" on the right side of "0-0";

on log	o relea	sed 🔻			
set	time 🔻	to	running time (ms)	-•	start 🔹

Enter"Basic"module to find and drag"show number"into"on logo released"block;

Enter"Math" module to find and drag"square root 0" into"0";

Click the little triangle to find"integer÷";

on logo released 🕶			
set time → to	running time (ms)	- •	start •
show number 0	integer ÷ 🔹 📀		+ +

Enter"Variables" module to find and drag"time" into"0" on the left side of "0-0" and change the "0" on the right side to "1000";



Complete Program

	①Touch the logo on the micro:bit with hand;
on logo touched - set start - to running time (ms)	②Assign "running time" to variable"start"; ③LED dot matrix displays pattern"";
show icon	@Put your hand away from the logo;
set time ▼ to running time (ms) - ▼ start ▼	⑤Assign "running time" to variable "time"
show number time ▼ integer ÷ ▼ 1000	©LED dot matrix displays the integer of variable "time"divided by 1000.

Select"JavaScript" and "Python" to switch into JavaScript and Python language code:

	🔹 Blocks	JavaScript	~	?	٠	Microsoft
Search Basic	Q	1 let start = 2 let time = 0 3 input.onLogo	0) Event(TouchButto	onEvent.Touc	hed,	function () {
InputMusic		4 start = 5 basic.sh 6 })	input.runningTim owIcon(IconNames	ne() .Heart)		
C Led		7 input.onLogo 8 time = i 9 basic.sh	Event(TouchButto nput.runningTime wNumber(Math.io	onEvent.Rele e() - start div(time, 10	eased, 000))	<pre>function () {</pre>
C Loops	1	0 }) 1				

	*	Blocks		Python	v l			?	٠	Microsoft
Search Basic Input Music Led All	Q	3 5 6 7 8 9 10 11	def inpu def	on_logo_ta global sta start = in basic.shou t.on_logo_ on_logo_ra global tin	ouched(): art mput.runni w_icon(Ico _event(Tou eleased(): me	ng_time() nNames.HEA chButtonEve	RT) ent.TOU	CHED,	on_lo	ogo_touched)
C Loops		12 13 14 15	inpu	time = in basic.show t.on_logo_	put.runnin w_number(M _event(Tou	g_time() - ath.idiv(t: chButtonEve	start ime, 10 ent.REL	00)) EASED), on_:	logo_released)

4.Test Results:

Uploading the test code to micro:bit main board V2 and powering the board via the USB cable, the LED dot matrix exhibits the heart pattern when the touch-sensitive logo is pressed or touched and displays digit when the logo is released.

6.11 Project 11: Microphone



1.Project Description:

The built-in microphone of micro:bit V2 can test the sound volume in the ambient environment. When you clap, the microphone LED indicator will be on.

Since it can measure the intensity of sound, you can make a noise scale or disco lighting changing with music. The microphone is placed on the opposite side of the microphone LED indicator and in proximity with holes that lets sound pass. When the board detects sound, the LED indicator will light up.

2.Components Needed:

- Micro:bit main board V2 *1
- Micro USB cable*1

3.Test Code 1

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor,

Delete block"on start"and"forever";

Enter"Input"module to find and drag"on loud sound";

Enter"Basic" module to find and drag "show number" into "on loud sound" block ;



Click the little triangle of "lond" to choose"quiet";



Complete Program



Select"JavaScript" and "Python" to switch into JavaScript and Python language code:



4.Test Results 1:

Uploading test code to micro:bit main board V2 and powering the board via the USB cable. The LED dot matrix

displays pattern", "when you clap; however, the image will appear when it is quiet around.

5.Test Code 2:

Link computer with micro:bit board by micro USB cable, and program in MakeCode editor,

 $Enter ``Advanced'' module \rightarrow choose ``Serial'' to find and drag ``serial redirect to USB'' into ``on start'' block ;$



 $\label{eq:choose} Enter ``Variables'' module \rightarrow choose ``Make a Variable'' \rightarrow input ``maxSound'' \rightarrow click ``OK'', variable ``maxSound'' is established;$

Enter"Variables" module to find and drag" set maxSound to 0" into "on start" block ;



Enter"Logic"module to find and drag"if true then...else"into "forever" block ; Enter"Input"module to find and dragbutton A is pressed"into "then" ;

pressed	hen
	Θ
	Dressed (

Enter"Basic"module to find and drag"show number"into "then"; Enter"Variables"module to find and drag"maxSound"into "0";

forever						
if	button	A 🔻	is p	oresse	ed	then
show	number	maxS	ound	D		
else						Θ

Establish variable"soundLevel";

Enter"Variables" module to find and drag"set soundLevel to 0" into "else";

Enter"Input" module to find and drag"sound level" into "0";



Enter"Led" module to find and drag"plot bar graph of 0 up to 0" into"else";

Enter"Variables" module to find and drag"soundLevel" into the"0" behind "of";

Change the"0"behind"up" to"255";



Enter"Logic"module to find and drag"if true then"into "else"block ;

Enter"Logic"module to find and drag"0 > 0"into "then";

Enter"Variables" module to find and drag"soundLevel" into "0" on the left side of "0-0";

Enter"Variables" module to find and drag"maxSound" into "0" on the right side;

forever					
if button A	🔹 is presse	d then			
show number	naxSound 🔹				
else		Θ			
set soundLev	el 🔻 to 🛛 sou	nd level			
plot bar graph up to 255	n of soundLev	rel 🔻			
if sound	Level 🔻 > 🔻	maxSou	nd 🔻	t	hen
\odot					

Enter"Variables" module to find and drag"set maxSound to 0" into the second"then"; Enter"Variables" module to find and drag"soundLevel" into the"0";

forever			
if button #	🔹 is pressed	then	
show number	maxSound 🔹		
else		Θ	
set soundLev	el 💌 to 🛛 soun	d level	
plot bar grap	n of soundLeve		
up to 255			
if sound	Level 🔻 🔉 🔻	maxSound •	then
set maxSou	nd 🔻 to sound	dLevel 🔹	
\odot			
0			

Complete Program



Select"JavaScript" and "Python" to switch into JavaScript and Python language code:



6.Test Results 2:

Math

ш

Upload test code to micro:bit main board V2, power the board via the USB cable and click"Show console Device"as shown below.

15



When the sound is louder around, the sound value shows in the serial port is bigger as shown below.

128	← Go back	Device	11 📩 🕫
			195.00
■ 2 ± +0 S	195 A. Ma AN	l	.ee
() () () () () () () () () ()			
III Show console Simulator			
III Show console Device			
* 2 (^			
	95		
	127		
	153 172		
	187		
	2 187		
	191		
	3 195		-

What's more, when pressing the button A, the LED dot matrix displays the value of the biggest volume(please note that the biggest volume can be reset via the Reset button on the other side of the board) while when you clap, the LED dot matrix will show the pattern of the sound.

6.12 Project 12: Bluetooth Data Reading



1.Project Description:

The Micro: bit main board V2 comes with a nRF52833 processor (with built-in Bluetooth 5.1 BLE(Bluetooth Low Energy) device) and a 2.4GHz antenna for Bluetooth wireless communication and 2.4GHz wireless communication. With the help of them, the board is able to communicate with a variety of BT devices, including smart phones and tablets.

In this project, we mainly concentrate on the BT wireless communication function of this main board. Linked with BT, it can transmit code or signals. To this end, we should connect an Apple device (a phone or an iPad) to the board.

Since setting up Android phones to achieve wireless transmission is similar to that of Apple devices, no need to illustrate again.

2.Preparation

*Attach the Micro:bit main board V2 to your computer via the Micro USB cable.

*An Apple device (a phone or an iPad) or an Android device;

3. Procedures:

For Apple devices, enter this link https://www.microbit.org/get-started/user-guide/ble-ios/ with your computer first, and then click "Download pairing HEX file" to download the Micro: Bit firmware to a folder or desk, and upload the downloaded firmware to the Micro: Bit main board V2.



If you need help

If you're having problems flashing code from your iOS device to your micro:bit, download this HEX file and transfer it to your micro:bit from a computer, or visit our support site.

Download pairing HEX file



Monitor and control

The 'Monitor and control' section of the iOS app allows you to observe real-time data from the micro:bit sensors, send messages directly to the LEDs and control the micro:bit buttons and pins from your iPad or iPhone.

🖊 🕑 📙 🖛 Download	ds	– 🗆 X
File Home Share	View	~ 📀
← → ~ ↑ ↓ > Th	is PC > Downloads	් Search Downloads , p
📌 Quick access	microbit-pair-ios.hex	
📃 Desktop 🛛 🖈	Open with	
🕂 Downloads 🛛 🖈	Scan with Windows Defender	
🔮 Documents 🛛 🖈	🖻 Share	
📰 Pictures 🛛 🖈	Give access to >	
This PC	Restore previous versions	
	Send to >	8 Bluetooth device
	Cut	Compressed (zipped) folder
Network	Сору	Desktop (create shortcut)
	Create shortcut	🚊 Documents
	Delete	Hax recipient
	Rename	MICRORIT (E)
	Properties	
litem litem selected b	30 M	
📙 🛃 📕 🔻 New folder		- 🗆 ×
File Home Share	View	~ 🚱
\leftrightarrow \rightarrow \uparrow \uparrow \bullet This	PC > Desktop > New folder	✓ O Search N
A Quick access	microbit-pair-ios.hex	
📃 Desktop 🛛 🖈		
	53% complete	– 🗆 🗙
👆 Downloads 🛛 🖈	■ 53% complete	- 🗆 X
➡ Downloads	 53% complete Copying 1 item from New folder to MICROBIT (E:) E 20% computate 	- • ×
 ➡ Downloads ★ ➡ Documents ★ ➡ Pictures 	 53% complete Copying 1 item from New folder to MICROBIT (E:) 53% complete 	- • ×
 Downloads Documents Pictures This PC 	 53% complete Copying 1 item from New folder to MICROBIT (E:) 53% complete 	- • ×
 Downloads Documents Pictures This PC 3D Objects 	 53% complete Copying 1 item from New folder to MICROBIT (E:) 53% complete 	
 Downloads Documents Pictures This PC 3D Objects Desktop 	 53% complete Copying 1 item from New folder to MICROBIT (E:) 53% complete 	- ×
 Downloads Documents Pictures This PC 3D Objects Desktop Documents 	 53% complete Copying 1 item from New folder to MICROBIT (E:) 53% complete Mame: microbit-pair-ios.hex 	- ×
 Downloads Documents Pictures This PC 3D Objects Desktop Documents Documents Downloads 	 53% complete Copying 1 item from New folder to MICROBIT (E:) 53% complete Mame: microbit-pair-ios.hex Time remaining: Calculating 	- X
 Downloads Documents Pictures This PC 3D Objects Desktop Documents Downloads Music 	 53% complete Copying 1 item from New folder to MICROBIT (E:) 53% complete Mame: microbit-pair-ios.hex Time remaining: Calculating Items remaining: 1 (841 KB) 	- X
 Downloads Documents Pictures This PC 3D Objects Desktop Documents Downloads Music Pictures 	 53% complete Copying 1 item from New folder to MICROBIT (E:) 53% complete S3% complete Name: microbit-pair-ios.hex Time remaining: Calculating Items remaining: 1 (841 KB) 	- X

Search"micro bit"in your App Store to download the APP micro:bit.



Connect your Apple device with Micro: Bit main board V2:

Firstly, turn on the Bluetooth of your Apple device and open the APP micro:bit to select item "Choose micro:bit"to start pairing Bluetooth.

Please make sure that the Micro: Bit main board V2 and your computer are still linked via the USB cable.

Menu	💿 micro:bit		Help
	Choose micro:bit	0	
	Create Code	Ľ	
	Flash	ፍ	
	Monitor and Control	也	
	ldeas	വ	

Secondly, click"Pair a new micro:bit";

〈 Home	Choose micro:bit	Help
	Currently selected micro:bit	
	None selected	
	If you want to use a new micro:bit, tap the button below.	
	If you want to remove a pairing from a micro:bit, go to the Bluetooth section in your device Settings.	
	Having problems? Try the Help page.	
	Pair a new micro:bit 😋	

Following the instructions to press button A and B at the same time(do not release them until you are told to) and press Reset & Power button for a few seconds.

Release the Reset & Power button, you will see a password pattern shows on the LED dot matrix. Now , release buttons A and B and click Next.





Set the password pattern on your Apple device as the same pattern showed on the matrix and click Next.

Enter pattern	
Ooh,	pretty!
Step 2	
COPY the pattern from your device and TAP Next	
Cancel X Next	>

Still click Next and a dialog box props up as shown below. Then click "Pair". A few seconds later, the match is done and the LED dot matrix displays the "" pattern.



After the match with Bluetooth, write and upload code with the App.

Click"Create Code"to enter the programming page and write code.

	Create a Project	0	
Ð	Give your project a name.		
New Project Click a lect "Create ".	nd the box.	Create 🗸	appears, and then se-
Menu	💿 micro:bit		Help
Choo	ose micro:bit	0	
Crea	te Code	Ľ	
Flash	1	F	
Moni	tor and Control	ц	
Ideas	5	വ	



🖸 micro:bit 🛛 🖀 Hom	ie < 🔹 Bloci	ks 🗾 JavaScript 🗸	•	٠		Microsoft
	Search Q Search Q Searc	on start led enable true • forever show leds				
	C Loops C Logic Variables Math ✓ Advanced	pause (ms) 500 v show leds				
		pause (ms) 500 •				
🛓 Download	Pick a name		0 }	د ر	٣	• •
Name the code as"1" and click	🛓 Download	••• 1			8	to save it.



Click the third item "Flash" to enter the uploading page. The default code program for uploading is the one saved just now and named "1" and then click the other "Flash" to upload the code program "1"

Menu Omicro:bit	Help
Helo	
Choose micro:bit	0
Create Code	
Flash	[ţ]
Monitor and Control	Ŀ
ldeas	С

Home		Flash		Help
•	OK. Let's do this	BBC mi	cro:bit [zivip]	
	1 sample: monito sample: camera Wednesday, May 6, 20 9:32:08 AM Flash	or-services a-control 020		
	Code Editor		ď	



If the code is uploaded successfully a few seconds later, the App will emerge as below and the LED dot matrix of the Micro: Bit main board V2 will exhibit a heart pattern.



Projects below all conduct with the built-in sensors and the LED dot matrix while the following ones will carry out with the help of external sensors/modules of EASY Plug Shield for micro bit V1.1.

6.13 Project 13: LED Blink

1.Description

LED blink is a basic experiment. You will learn how to make white LED blink through code. Please turn off dot matrix on micro:bit before testing.

2.What You Need:

- Micro:bit Board*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1

- EASY Plug White LED Module*1
- RJ11 Cable*1
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

3.EASY Plug White LED Module



The LED light modules have shiny colors, ideal for Arduino starters. It can be easily connected to IO/Sensor shield.

Note: this module needs to be used together with EASY Plug Shield for micro bit V1.1. You can also choose other LED to emit different color of light like white, blue, green, yellow and red.

4.Specification

- Interface: Easy plug
- Sensor type: Digital
- Working voltage: 5V
- Easy to use
- Useful for light projects

EASY Plug Shield for micro:bit V2

https://www.gstatic.cn/supportcn/translate/index

https://policies.google.com/?hl=zh-CNhttps://www.google.com/about?hl=zh-CN

Micro:bit is a basic development board designed by the British Broadcasting Corporation for youth programming education. It supports the PXT graphical programming interface developed by Microsoft, without the need to download an additional compiler, and can be used under Windows, macOS, IOS, Android and other operating systems.

We combine the EASY Plug shield with the micro:bit due to the inconvenience of wiring up micro:bit .

The golden finger interfaces, as well as 10 pcs easy plug ports (RJ11 6P6C interfaces)could be connected to other modules and sensors, therefore, you don't need to worry about wiring up components incorrectly.

The shield comes with 4 pcs WS2812 LEDs controlled by P9, P0 controls passive buzzer; and two dial switches–Power_Switch and Voltmeter_Switch(3.3V, 5V).

The voltage of power supply is DC 6-10V

The Easy Plug port only supports the sensors and modules with RJ11 6P6C port.

Specification



Power supply: DC 6-10VOutput current: 1.5AInterface: RJ11 6P6C interface and golden finger interfaceSize: 986517mm**5.Interface Description**GGNDV: Voltmeter_Switch controldial to 5V end5Vdial to 3V end, 3.3VI2C Communication PortSDAP20SCLP19SPI Communication PortImage: Supple Su

SCKP13

6.Wiring Up


Note: Dial Voltmeter_Switch to 3V end

7.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

+ + + +	+	+	+	+	
on start	+				
led enable false	•				
forever	+	+	-		"on start" : command block only runs
digital write pin	P12 🔻	to	1		once to start program. Turn off dot matrix on micro:bit
pause (ms) 1000	+	+	-		The program under the block "forever"
digital write pin	P12 🔻	to	0		
pause (ms) 1000	+	+	+		Set P12 to high level(1) turn on LED
	+				Delay in 1000ms
+ + + +					Set P12 to low level (0) turn off LED
+ + + +	+	+	+	+	Delay in 1000ms

8.Test Results:

Wire up, dial Voltmeter_Switch to 5V end, plug in external power and dial Power_Switch to ON end. Upload code to the micro:bit and you will view LED flashing, with interval of 1s.

6.14 Project 14: Breathing Light

1.Description

The light breath experiment is a little bit similar to the previous project. This time we connect the EASY Plug Red Led module to the EASY Plug Shield for micro bit V1.1. Connect the pin of LED module to P10 of micro:bit. From the Pinout diagram of micro:bit, you can get the P10 can be used as Analog IN.

This lesson you will learn how to control the brightness of LED on the module, gradually becoming brighter and dimming, just like the LED is breathing.



2.What You Need:

- Micro:bit Board*1EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY Plug Red LED Module*1
- RJ11 Cable*1
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

3.Wiring Up

Insert micro:bit onto EASY Plug shield, connect red LED module to P10 of shield with a RJ11 cable, and plug in external power.



Note: Dial Voltmeter_Switch to 3V end

4.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.



5.Test Results

Wire up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

You will find LED of module get brighter then darker, like human breath.

6.15 Project 15: Blink and Breath

1.Description

In this project, we will combine LED flash and breathing effect together.

2.What You Need:

- Micro:bit Board*1EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY Plug Red LED Module*1

- RJ11 Cable*1
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

3.Wiring Up

Insert the micro:bit onto EASY Plug shieldconnect the red LED module to P10 of shield with a RJ11 cable and connect external power.



Note: Dial Voltmeter_Switch to 3V end

4.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.



5.Test Results

Wire up, dial Voltmeter_Switch to 3V end, plug in power and dial Power_Switch to ON end. Upload program to micro:bit, LED flashes twice and shows breathing effect twice ceaselessly.

6.16 Project 16: Play Music

1.Description

In this project, we will demonstrate how to play music with passive buzzer. Easy Plug shield comes with one. Let's get started. (Passive buzzer is connected to P0 on Easy Plug shield)

2.What You Need:

- Micro:bit Board*1EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

Passive Buzzer Module:



https://www.gstatic.cn/supportcn/translate/indexhttps://policies.google.com/?hl=zh-CNhttps://www.google.com/ about?hl=zh-CN

Buzzers are divided into active buzzers and passive buzzers. The difference between them is a built-in vibration source.

We need 2K-5K square wave to drive passive buzzers because the buzzer on EASY Plug Shield doesn't come with this kind of source.

Different frequencies produce different sounds. You can use the micro:bit to produce a simple, interesting and melodic song.

3. Specification

Working voltage: 3.3-5V

Interface type: Digital

4. Wiring Up



Note: Dial Voltmeter_Switch to 3V end.

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

Code 1:





	play tone High D for 1/2 ▼ beat	
n start	alay tang Wigh C fan 1/2 x haat	
led enable false 🔻	play tone High C for 1/2 beat	
	play tone (High C) for 2 • beat	
orever	play tone High D for 2 • beat	
play tone High E for 2 • beat	play tone High E for 1 * beat	
play tone High F for 1 • beat	play tone High C for 1 • beat	
play tone High G for 2 🔻 beat	play tone (High D) for 1 * beat "on start": command block or to start program.	ly runs once
play tone High F for 1 • beat	play tone (High E) for 1/2 The maximum under the black	o:bit
play tone High E for 1 • beat	play tone (High F) for 1/2 ▼ beat	en ivievel
play tone High D for 1 • beat	play tone (High E) for 1 • beat Play tone High E for leat Play tone high G of 2 beats Play tone bioh F for 1 beat	
play tone High C for 2 • beat	play tone High C for 1 < beat	
play tone High D for 1 • beat	play tone High D for 1 < beat Play tone high C for 2 beats Play tone high D for 1 < beat Play tone high E for 2 beats	
play tone High E for 2 • beat	play tone High E for 1/2 ▼ beat Play tone high D for 2 beat Play tone high D for 2 beat Play tone high D for 2 beats Play tone high E for 2 beats	
play tone High E for 1/2 • beat	play tone High F for 1/2 ▼ beat Play tone high F for 1 be	
play tone High D for 1/2 • beat	play tone High E for 1 veat Play tonehigh 2 for 1 beat Play tonehigh 2 for 1 beat Play tonehigh 2 for 2 beats Play tonehigh 2 for 2 beats Play tonehigh 2 for 1 beat	
play tone High D for 2 - beat	play tone High D for 1 < beat	
play tone High E for 2 🔻 beat	Play tone High C for 1 ▼ beat Play tone high D for 1/2 beat Play tone high C for 1 ≥ beat Play tone high C for 1 beat Play tone high C for 1 beat Play tone high D for 2 beats	
play tone High F for 1 T beat	play tone High D for 1 • beat Play tone high E for 1 beat Play tone high D for 1 • beat	1/2
play tone High G for 2 - beat	play tone Middle G for 1 v beat Play tone high E for 1/2 beat Play tone high E for 1/2 beat Play tone high E for 1 beat Play tone high E for 1 beat Play tone high E for 1 beat	2.
play tone High F for 1 V beat	play tone Low E for 1 beat Play tone high E for 1/2 beat Play tone high F for 1/2 beat	t 1 -
play tone High E for 1 • beat	play tone (High E) for 2 • beat	
play tone High D for 1 - beat	play tone High F for 1 • beat Play tonehigh E for 1 beat Play tonehigh E for 1 beat	
play tone High C for 2 - beat	play tone High G for 2 • beat Play tonehigh F for 1 beat Play tonehigh F for 1 beat	1/2
play tone High D for 1 - beat	play tone High F for 1 > beat	1/2
play tone High E for 1 • beat	play tone High E for 1 beat Play tone high C for 2 beats Play tone high D for 1 beat Play tone high D for 1 beat Play tone high E for 1 beat	1/2
play tone High D for 1 • beat	play tone (High F) for 1/2 ▼ beat Play tone high D for 1 beat Play tone high C for 1/2 beat Play tone high C for 1/2 beat Play tone high C for 1/2 beat Play tone high C for 1/2 beat	2

eat) eat

Note: Clic	to switch into JavaScript code, each frequency and beat of tone is
	🖹 Blocks 🗾 JavaScript 🗸
1	<pre>led.enable(false)</pre>
2	<pre>basic.forever(function () {</pre>
3	<pre>music.playTone(659, music.beat(BeatFraction.Double))</pre>
4	<pre>music.playTone(698, music.beat(BeatFraction.Whole))</pre>
5	<pre>music.playTone(784, music.beat(BeatFraction.Double))</pre>
6	<pre>music.playTone(698, music.beat(BeatFraction.Whole))</pre>
7	<pre>music.playTone(659, music.beat(BeatFraction.Whole))</pre>
8	<pre>music.playTone(587, music.beat(BeatFraction.Whole))</pre>
9	<pre>music.playTone(523, music.beat(BeatFraction.Double))</pre>
10	<pre>music.playTone(587, music.beat(BeatFraction.Whole))</pre>
11	<pre>music.playTone(659, music.beat(BeatFraction.Double))</pre>
12	<pre>music.playTone(659, music.beat(BeatFraction.Half))</pre>
13	<pre>music.playTone(587, music.beat(BeatFraction.Half))</pre>
14	<pre>music.playTone(587, music.beat(BeatFraction.Double))</pre>
15	<pre>music.playTone(659, music.beat(BeatFraction.Double))</pre>
16	<pre>music.playTone(698, music.beat(BeatFraction.Whole))</pre>
17	<pre>music.playTone(784, music.beat(BeatFraction.Double))</pre>
18	<pre>music.playTone(698, music.beat(BeatFraction.Whole))</pre>
19	<pre>music.playTone(659, music.beat(BeatFraction.Whole))</pre>
20	<pre>music.playTone(587, music.beat(BeatFraction.Whole))</pre>
21	<pre>music.playTone(523, music.beat(BeatFraction.Double))</pre>
22	<pre>music.playTone(587, music.beat(BeatFraction.Whole))</pre>
23	<pre>music.playTone(659, music.beat(BeatFraction.Whole))</pre>
24	<pre>music.playTone(587, music.beat(BeatFraction.Whole))</pre>
25	<pre>music.playTone(587, music.beat(BeatFraction.Half))</pre>

6. Test Results

Wire up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code 1 to micro:bit. Then you will hear the buzzer emit two kind of sounds; if you download code 2 to the micro:bit, the song"Ode-to- Joy" will be played.

6.17 Project 17: RGB

Description

EASY Plug shield comes with 2812 2x2 full color RGB lights, we will finish three experiments with 2812 2x2 RGB lights

What You Need:

- Micro:bit Board*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

2812 2x2 full color RGB



2812 2x2 full color RGB module is a smart external control LED light source that integrates control circuit and lighting circuit.

Each LED has the same appearance as a 5050 LED bead, and each component is a pixel point.

The pixel point includes an intelligent digital interface data latch signal shaping and amplifying driving circuit, as well as a high-precision internal oscillator and a 12V high-voltage programmable constant current control part, which effectively ensures that the color of the pixel point light is highly uniform.

The data protocol adopts the single-line return-to-zero code communication mode. After power-on and reset the pixel point, the S pin receives the data transmitted from the controller. And the 24-bit data are extracted by the first pixel and then sent to the data latch inside the pixel point.

LED has advantages of low voltage drive, environmental protection and energy saving, high brightness, wide scattering angle, good consistency, ultra low power, long life and so on.

Specification

Working voltage: DC 5V Power: 0.1W Light source: SMD 5050 RGB IC model: 4pcs/WS2811 Gray level: 256 levels Beam angle: 180° Luminous color: can be adjusted to white, red, yellow, blue, green, etc. by the controller

Wiring Up



Note: Dial Voltmeter_Switch to 3V end

Test Code:

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

We need to set test code in library file, and add the library of "neopixe".

3	Game	
	Images	
0	Pins /	
• 4	Serial	
188	Control	
Ο	Extensions	Ţ

 $Click``Extensions" \rightarrow ``neopixel" and click to download$



You will view library"neopixel"in the editing blocks, as shown below:



Code 1:



Code 2



Code 3:



Test Results

Wiring up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and download code 1 to micro:bit, WS2812RGB lights display different color.

Download code 2 to micro:bit, WS2812RGB show same color like flow light.

Download code 3 to micro:bit, each WS2812RGB shows random color like flow light.

6.18 Project 18: Button Control

1.Description:

Button sensor is commonly used component. In this chapter, we will show you how to control an LED with a button sensor.

2. What You Need:

- Micro:bit Board*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY Plug Digital Push Module*1
- EASY Plug White LED Module*1
- RJ11 Cable*2
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug Button



The EASY Plug digital push module is a tidy little design that lets you control a DC power source using an everyday tactile button.

It can be connected to circuit. When it it pressed, the circuit is connected, when released, the circuit is cut.

3. Specification:

- Connector: Easy plug
- Supply Voltage: 3.3V to 5V
- Large button and high-quality top cap

- Sensor type: Digital
- Weight: 5.6g

4.Wiring Up

Insert micro:bit onto EASY Plug shield, wire up digital push module and LED module to P10 and P12 port of shield and RJ11cables. Don't forget to connect battery holder.



Note: Dial Voltmeter_Switch to 3V end

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.



6. Test Results

Wiring up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

Press button sensor, LED will be on; press button again, LED off.

6.19 Project 19: Tilt Control

1. Description

Tilt sensor (tilt ball switch) allows you to detect orientation or inclination.

They are small, inexpensive, low-power and easy-to-use.

We will try to control an LED with a tilt sensor.

2.What You Need:

- Micro:bit Board*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY Plug Digital Tilt Sensor*1
- EASY plug Red LED Module*1
- RJ11 Cable*2
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug Digital Tilt Sensor:



This EASY Plug digital tilt sensor module mainly integrates a tilt sensor. The tilt sensor is a component that can detect the tilt of an object. It uses the ball in the switch to change different inclination angles to trigger the circuit. When the ball in the tilt switch runs from one end to the other due to the vibration of an external force, the tilt switch will be turned on, otherwise it will be turned off. The tilt sensor can be applied in orientation detection and alarm.

3.Schematic Diagram



Closed circuit

Specification:

Connector: Easy plug

Supply Voltage: 3.3V to 5V

Sensor type: Digital

Dimensions: 39mm*20mm*18mm

Weight: 4.8g

4.Wiring Up

Insert the micro:bit onto EASY Plug shield, connect a digital tilt sensor and an LED module to P1 and P12 port of shield. And plug in power.



Note: Dial Voltmeter_Switch to 3V end

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.



6.Test Result

Wire up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

When tilt sensor is inclined to the right, micro:bit shows 0, and LED is on; when inclined to the left, micro:bit displays 1 and LED is off.

6.20 Project 20: Relay Module

1.Description

Generally, we drive electronic devices with 220V alternating current and connect a switch in 220V circuit.

We design the Easy Plug relay module with NO and NC end to constrain from the risk of electricity leakage.

In this experiment, we will show you how to control a relay module.

This module integrates a high-quality relay, basically an electrically controlled mechanical switch.

It can be controlled through the digital IO port, such as lamps, motors and other high current or high voltage devices.

2.What You Need:

- Micro:bit Board*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1

- EASY plug Relay Module*1
- RJ11 Cable*1
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug Relay Module:



It is one of the most important controlled elements, which is widely used to control the lighting, communications, remote sensing, electrical and other equipment.

When S end is set high level, relay is driven, that is NO is connected, NC off; when S end is low level, relay is closed, that is NO is disconnected and NC is connected.

3. Specification:

- Type: Digital
- Rated current: 10A (NO) 5A (NC)
- Maximum switching voltage: 150VAC 24VDC
- Interface: Digital
- Control signal: TTL level
- Rated load: 8A 150VAC (NO), 10A 24VDC (NO), 5A 250VAC (NO/NC), 5A 24VDC (NO/NC)
- Maximum switching power: AC1200VA DC240W (NO), AC625VA DC120W (NC)
- Contact action time: 10ms
- Size: 40*28mm
- Weight: 15g

4. Wiring Up

Insert micro:bit onto EASY Plug shield, connect relay module to P12 of shield with a JR11 cable, plug in power.



Note: Dial Voltmeter_Switch to 5V end

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.



6.Test Result

Wiring up, dial Voltmeter_Switch to 5V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

The relay module is connected and disconnected ceaselessly, with interval of 1s.

6.21 Project 21: Crash Sensor

1.Description

We detect collision with a crash sensor. When the metal switch is touched, it will output low level signals; when the metal switch is not touched, high level will be remained.

We will control an LED with a collision sensor

2. What You Need:

- Micro:bit Board*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY Plug Crash Sensor*1
- EASY Plug White LED Module*1
- RJ11 Cable*2
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug Crash Sensor:

Crash sensor, an electronic switch, is a digital switch input module.



1. When collision happens upfront of where crash module is installed, module outputs low level signal; no collision, outputs high level signal.

2. With a mounting hole, convenient for fixation on any devices.

3. PCB size: 3.1cm * 2.1cm

4. With switch indicator light, if there is collision, LED on; if no collision, LED off.

5.Connector: Easy plug

6.On-board status indicator LED

7.M3 mounting hole, convenient for fixation on other devices.

3. Wiring Up

Insert micro:bit onto EASY Plug shield. Connect crash sensor and LED module to P1 and P12 port of shield. Plug in external power.



Note: Dial Voltmeter_Switch to 3V end

4. Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.



5. Test Result

Wire up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

When the metal switch of crash sensor is pressed, the value low level(0) will be displayed and the LED will be on; on the contrary, micro:bit will show high level(1), LED will be off.

6.22 Project 22: Follow Black Line

1.Description

We will make smart robot follow the black lines to drive. Does it sound unbelievable?

Combine line tracking sensor with the micro:bit, then we could achieve what we want.

2.What You Need:

- Micro:bit Board*1EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY Plug Line Tracking Sensor*1
- RJ11 Cable*1
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug Line Tracking Sensor:



As an IR sensor, the line tracking sensor can detect black and white lines.

It has a TCRT5000 photoelectric sensor. Infrared reflectivity of color is different, which is applied to convert strong and weak echoed signal into current signal. The signal end will output high level when no object or black line is detected; otherwise, the low level will be output. As a result, we could determine color by high or low level from signal end.

Note: rotate the potentiometer to keep LED in on-and-off state that stands for high sensitivity.

3. Specification:

- Power supply: +5V
- Operating current: <10mA
- Operating temperature range: $0^{\circ}C \sim + 50^{\circ}C$
- Output interface: Easy plug
- Output Level: TTL (Black for HIGH output, White for LOW output)
- Detection Height: 0-3 cm

4. Wiring Up

Insert micro:bit onto EASY Plug shield, connect line tracking sensor to P1 port of shield, and plug in power.



Note: Dial Voltmeter_Switch to 3V end

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.



6.Test Result

Wire up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

The signal end will output high level when no object or black line is detected; otherwise, the low level will be output. As a result, we could determine color by high or low level from signal end.

6.23 Project 23: Magnetic Detection

1.Description

Hall magnetic sensor has the characteristic of high sensitivity, quick-response, high reliability and high performance.

We will teach you how to control the on-and-off state of LED and detect if there is magnetic field with hall magnetic sensor.

2. What You Need:

- Micro:bit Board*1EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1

- EASY Plug Hall Magnetic Sensor*1
- EASY Plug Blue LED Module*1
- RJ11 Cable*2
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug Hall Magnetic Sensor:



Applied to detect magnetic field and output digital signals, this Hall magnetic sensor adopts a A3144E component. It can detect if there exists magnetic field rather than how strong it is.

3. Specification:

- Power supply: +5V
- Sensing magnetic materials
- Detection range: up to 75px
- Output: Digital High/Low
- Detection range and magnetic field strength are proportional

4. Wiring Up

Insert the micro:bit onto EASY Plug shield, connect the hall magnetic sensor and a blue LED module to P1 and P12 port of shield with 2 RJ11 cables. And plug in power.



Note: Dial Voltmeter_Switch to 3V end

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.



Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

6. Test Result

Wire up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

Place a magnetic bead nearby the hall magnetic sensor, micro:bit will display 0(low level) and LED will be on if sensor detects the magnetic field; conversely, 1 will appear on micro:bit and LED will be off.

6.24 Project 24: 4-digit LED Display

1. Description

In this lesson, we will teach you how to display numbers on EASY Plug 4-digit LED module.

2. What You Need:

- Micro:bit Board*1EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY plug 4-digit 8-segment Display Module*1
- RJ11 Cable*1
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY plug 4-digit LED display



This is a 4-digit 0.36" common anode LED display module, a 12-pin display module with score points.

The driver chip used in the matrices is TM1637, using only two signal cables to make the microcontroller control the 4-digit LED display.

The four pins of LED display are GNDVCCDIOCLK. (GND is ground, VCC is for power supply, DIO is data IO pin, CLK is clock signal pin.)

The module pins are extended into Registered jack, so you can easily connect it to EASY Plug control board using a RJ11 cable.

This module should be used together with EASY plug control board.

3. Specification

- 1 Specification:
- 1 Working voltage: DC 5V
- 1 Operating temperature
- 1 range: -40+85°C
- 1 Size: 49.6*23 MM
- 1 Environmental protection attributes: ROHS

4. Wiring Up

Insert the micro:bit onto the EASY Plug shield, and connect the 4-digit tube module to P1-P2 port of shield.



Note: Dial Voltmeter_Switch to 3V end

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

Add the library of 4-digit tube module, as shown below:

Click"Extensions"



Input"TM1637" and searchas shown below, click to download

🗲 Go back	Extensions	2	?
TM1637		٩	
	18.88		
3	TM1637 LED Digit Display Module (TM1637)		
	Learn more		

After installing the library of 4-digit tube display module, you could view it in the editing blocks.



"on start": command block only runs once to start program.
Set item to CLK P2 DIO P1 intensity 7 LED count 4
The program under the block "forever" runs cyclically.
Open 4-digit tube
Delay in 200ms
Show 5 at the zero bit on 4-digit tube module.
Delay in 200ms
Show 5 at the first bit on 4-digit tube module.
Delay in 200ms
Display 5 at the second bit on 4-digit tube module.
Delay in 200ms
Display 5 at the third bit on 4-digit tube module.
Delay in 200ms
Turn off 4-digit tube
Delay in 200ms

6. Test Result

Wiring up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

The 4-digit tube module shows "5" from 0 bit to the third bit (From left to right are 0, 1, 2, and 3 bits). then the number "5555" flashes.

6.25 Project 25: Light Interrupter

1.Description

In our daily life, we often need to count and take measurement.

We could achieve goal by the combination of photo interrupter and microcontroller. We connect the photo interrupter to shield so as to control LED.

2. What You Need:

- Micro:bit Board*1EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY Plug Light Interrupter*1
- EASY Plug Red LED Module*1
- RJ11 Cable*2
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug Light Interrupter:



This is a high performance EASY Plug photo interrupter module.

The upright part on the module combines an infrared light emitting diode and shielded infrared detector.

By emitting a beam of infrared light from one end to another one, the sensor can detect an object when it passes through the beam.

Useful for many applications such as optical limit switches, pellet dispensing, general object detection, etc.

3. Specification:

- Support quick response; highly sensitive
- Interface: Easy plug
- Supply Voltage: 3.3V to 5V

4. Wiring Up

Insert the micro:bit onto the EASY Plug shield, connect light interrupter module and LED module to P0 and P12 port of shield.



Note: Dial Voltmeter_Switch to 3V end

5. Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.



6.Test Results

Wire up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code
to micro:bit.

Micro:bit will display high level(1) and LED will be on if there is object goes through U slot of light interrupter; if not, LED will be off.

6.26 Project 26: EASY Plug Reed Switch Module

1.Description:

In this project, we will detect magnetic field with reed switch, shied and micro:bit. We've take advantage of hall magnetic sensor to detect magnetic field in project 20. What's the difference between hall magnetic sensor and reed switch module? Let's get started.

2.What You Need:

- Micro:bit Board*1EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY plug Magnetic Switch *1
- EASY plug Red LED Module*1
- RJ11 Cable*2
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug Reed Switch Module:



This is a small device called a reed switch on the module.

When the device is exposed to a magnetic field, the two ferrous materials inside the switch pull together and the switch closes.

When the magnetic field is removed, the reeds separate and the switch opens. This makes for a great non-contact switch.

You can mount reed switch on the door for alarming purpose or as switches.

This sensor needs to be used together with EASY plug control board.

The reed switch is applied widely in home appliance, automobile, communication, industrial, health care and security, as well as other electronic devices like door magnet, reed relay and level gauge.

3.Specification:

- Interface: Easy plug
- Working voltage: DC 3.3V-5V
- Working current: 20mA
- Working temperature: 10°C to50°C
- Detection distance: 10mm

4. Wiring Up:

Insert the micro:bit onto the EASY Plug shield, connect reed switch and LED module to P1 and P12 port of shield.



Note: Dial Voltmeter_Switch to 3V end

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

on start clear screen forever forever forever if digital read pin Pl ♥ ♥ ♥ ♥ then digital write pin Pl2 ♥ to 1 f digital write pin Pl2 ♥ to 0 f digital write pin Pl2 ♥ to 0	Set P12 to low level(0), turn off LED	on start clear screen forever show number digital read pin Pl ▼ if digital read pin Pl ▼ else digital write pin Pl2 ▼ to 1 else ↓ digital write pin Pl2 ▼ to 0 ↓ digital write pin Pl2 ▼ to 0 ↓	"on start" : command block only runs once to start program. Turn off LED dot matrix The program under the block "forever" runs cyclically. Micro:bit shows the digital signal(1/0) If digital signal read by P1=0, there is magnetic field, execute the program under then block Set P12 to high level(1), turn on LED If digital signal read by P1=1, no magnetic field, execute the program under else block Set P12 to low level(0), turn off LED
--	---------------------------------------	---	---

6. Test Result

Wire up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end, download code to micro:bit. When the reed switch module detects magnetic field, micro:bit will show low level(0and LED will be on; on the contrary, high level(1) will be displayed and LED will be off.

6.27 Project 27: Hear Footstep

1.Description

In this project, we will connect sound sensor to shield and read analog value by detecting sound with micro:bit. The louder the sound is, the larger the analog value is.

2. What You Need:

- Micro:bit main board*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY plug analog sound sensor*1
- EASY plug White LED Module*1
- RJ11 Cable*2
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY plug Analog Sound Sensor:



The sound sensor mainly adopts a high-sensitivity microphone element and LM386 chip. High-sensitivity microphone components are used to detect external sounds. The LM386 chip can amplify the sound detected by the high-sensitivity microphone, and the maximum multiple is 200 times.

When in use, we can adjust the multiple of the sound by rotating the potentiometer on the sensor. Rotating potentiometer clockwise, the sound will be up to the maximum. This benefits us to make sound-activated robot, switch, alarm and so on.

3. Specification:

Supply Voltage: 3.3V to 5V Interface: Easy plug

4. Wiring Up

Insert micro:bit onto EASY Plug shield, respectively connect sound sensor and white LED to P1 and P12 of shield, and plug in power.



Note: Dial Voltmeter_Switch to 5V end.

5. Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

(Note: sound analog value could be adjusted



6. Test Result

Wiring up, dial Voltmeter_Switch to 5V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

Open CoolTerm, click Options and select SerialPort, set COM port and baud rate, set baud rate to 115200. Tap OK and Connect.

CoolTerm monitor will display the result, as shown below:

When the sound analog value is greater than 100, LED will be on, otherwise, LED will be off.

✓ Untitled_0 *	- 🗆 X
File Edit Connection View Window Help	
Image: New Open SaveImage: SaveImage: SaveImage: SaveImage: SaveNew Open SaveSaveConnectDisconnectClear	Image: DataImage: DataImage: DescriptionImage: DescriptionImage: DescriptionDataOptionsView HexHelp
voice:36	^
voice:1	
voice:1	
voice:12	
voice:1	
voice:1	
voice:1	
voice:15	
voice:1	
voice:42	
voice: 29	
voice:5	
voice:1	
voice:34	
voice:6	
voice:197	
	×
COM16 / 115200 -N-1 Connected 00:09:02	 TX RTS DTR DCD RX CTS DSR RI

6.28 Project 28: Rotary Potentiometer

1.Description

When doing experiments, we often use a 10K adjustable potentiometer. Rotating it can change analog value and you could check value on CoolTerm monitor. At same time, the brightness of LED connected to P10 gradually alters.

2. What You Need:

- Micro:bit main board*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY plug Rotary Potentiometer*1
- EASY plug Red LED Module*1
- RJ11 Cable*2
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

3. EASY Plug Rotary Potentiometer:



This EASY Plug rotary potentiometer is counted as a changeable resistor. In fact, it will change the resistance of changeable resistor when rotating potentiometer. We set the circuit, convert the change of resistance into the change of voltage.

4. Specification:

Supply Voltage: 3.3V to 5V

Interface: EASY Plug

5. Wiring Up

Insert micro:bit onto EASY Plug shield, connect analog potentiometer and red LED module to P1 and P10 port of shield. And plug in power.



Note: Dial Voltmeter_Switch to 3V end.

6. Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

on start	"on start" : command block only runs once to start
led enable false •	program.
forever	Turn off micro:bit
serial write value (val) = analog read pin P1 •	The program under the block " forever " runs
pause (ms) 100 •	cyclically.
analog write pin P10 • to map analog read pin P1 •	Serial writes the analog signal of adjustable
from low 0	potentiometer
from high 1023	Delay in 100ms
to low 0	Map the analog signal (0-1023) of potentiometer to
to high 255	analog value (0-255) of LED connected P10

7. Test Result

Wiring up, dial Voltmeter_Switch to 5V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

Open CoolTerm, click Options and select SerialPort, set COM port and baud rate, set baud rate to 115200. Tap OK and Connect.

CoolTerm monitor shows the detected value, rotate the potentiometer to adjust analog value. As the analog value rises, LED gradually gets bright; when the value reduces, LED gets dimmer.

✓ Untitled_0 *	_		\times
File Edit Connection View Window Help			
Image: New Open SaveImage: SaveI	ns View He	ex Help	
val:39 val:40 val:46 val:55 val:68 val:98 val:153 val:248 val:433 val:726 val:847 val:888 val:917 val:939 val:955 val:964 val:964 val:967 val:974 val:984 val:991 val:999 val:1007 val:1013 val:1019 val:1023 val:1023			~
COM16 / 115200 8-N-1	RTS 😔 D	TR 🌒 DO	CD
Connected 00:00:32	CTS 🌑 D	SR 🏾 🌑 RI	

6.29 Project 29: Alcohol Content in the Air

1.Description

In this program, we will conduct you how to detect alcohol content.

2. What You Need:

- Micro:bit Board*1EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY plug Analog Alcohol Sensor*1
- RJ11 Cable*1
- 6 AA Battery Holder*1

• 1.5V AA Battery*6

EASY Plug Analog Alcohol Sensor:



This analog gas sensor - MQ3 is suitable for detecting alcohol. It can be used in a Breath analyzer. Also it has high sensitivity to alcohol and low sensitivity to gas. You could adjust the sensitivity by rotating the potentiometer of sensor.

The higher the alcohol content is, the larger the analog value at A0.

3. Specification:

- Power supply: 5V
- Interface type: EASY Plug
- Simple drive circuit
- Stable and long service life
- Quick response and High sensitivity

4. Wiring Up

Insert micro:bit onto EASY Plug shield, connect alcohol sensor to P4 of shield and plug in external power.



Dial Voltmeter_Switch to 5V end.

5. Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

on start led enable false •	"on start" : command block only runs once to start program.
	Turn off dot matrix on micro:bit
forever serial write value "value" = analog read pin P4 •	The program under the block "forever" runs cyclically.
pause (ms) 100	Serial writes analog signals read by alcohol sensor Delay in 100ms

6.Test Result

Wiring up, dial Voltmeter_Switch to 5V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.(LED2 of sensor shows green color, and you could adjust potentiometer to keep LED on module in off-and-on state(the sensitivity is highest)

Open CoolTerm, click Options and select SerialPort, set COM port and baud rate, set baud rate to 115200. Tap OK and Connect.

Make alcohol gas close to alcohol sensor, CoolTerm serial monitor indicates that the analog value gets larger and larger and LED1 is on; on the contrary, the analog value gets smaller, LED1 will be off.

✓ Untitled_0 *	_		\times
File Edit Connection View Window Help			
Image: New Open SaveImage: SaveI	HEX View Hex	? Help	
analog signal:574 analog signal:578 analog signal:594 analog signal:616 analog signal:637 analog signal:653 analog signal:665 analog signal:665 analog signal:680 analog signal:689 analog signal:692 analog signal:693 analog signal:694 analog signal:694 analog signal:694 analog signal:694 analog signal:694 analog signal:694 analog signal:694 analog signal:694 analog signal:694 analog signal:692 analog signal:693 analog signal:694 analog signal:694 analog signal:692 analog signal:691 analog signal:691 analog signal:692 analog signal:691 analog signal:692 analog signal:693			
anaroy Siynar:00/			~
COM16 / 115200 3-N-1 Connected 00:25:17 Connected 00:25:17	TS 🕒 DTF TS 🌑 DSR	R 🍈 Do Ri	CD

6.30 Project 30: Ambient Temperature Detection

1.Description

We will detect the current temperature with EASY plug LM35 linear temperature sensor and display the results on CoolTerm monitor and dot matrix.

2. What You Need:

- Micro:bit Board*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY plug LM35 Temperature Sensor*1

- RJ11 Cable*1
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug LM35 Linear Temperature Sensor:



Based on semiconductor LM35 temperature sensor, LM35 linear temperature Sensor can be used to detect ambient temperature.

It can detect temperature between 0° ~100°. Sensitivity is 10mV per degree Celsius. The output voltage is proportional to the temperature.

3. Specification

Sensitivity: 10mV per degree Celsius

Functional Range: 0°C to 100°C

4. Wiring Up

Insert micro:bit onto EASY Plug shield, connect LM35 temperature sensor to P1 of EASY Plug shield with a RJ11 cable, and plug in external power.



Note: Dial Voltmeter_Switch to 3V end.

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

on start	
led enable true -	"on start" : command block only runs once to start program. open LED dot matrix on micro:bit
forever set Temp ▼ to 300 × ▼ analog read pin P1 ▼ integer + ▼ 1023	The program under the block "forever" runs cyclically.
<pre>show number Temp serial write value 'Temp(C)' = Temp </pre>	Set temp to 300*analog read pin P1 integer÷1023 Display temperature value on micro:bit Serial writes temperature value
pause (ms) 100 V	Delay in 100ms

6.Test Result

Wiring up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

Open CoolTerm, click Options and select SerialPort, set COM port and baud rate, set baud rate to 115200. Tap OK and Connect.

Micro:bit and CoolTerm monitor will display the current temperature, as shown below:



6.31 Project 31: Water Level Alarm

Description

In this lesson, we will do an experiment with a water level sensor and a passive buzzer. Measure the water level in the cup, if water level rises up, LED will flash and passive buzzer will emit sound.

What You Need:

- Micro:bit Board*1EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY plug Water Level Sensor*1
- EASY plug Red LED Module*1
- RJ11 Cable*2
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug Water Level Sensor:



The water level sensor is easy- to-use, portable and cost-effective, designed to identify and detect water level and water drop.

This sensor measures the volume of water drop and water quantity through an array of traces of exposed parallel wires.

Characteristic:

Conversion of water volume and simulated water volume;

Strong flexibility, can output analog value;

Low power consumption, high sensitivity;

Can be directly connected to microprocessors or other logic circuits, suitable for Arduino controllers, STC microcontrollers, AVR microcontrollers and other development boards and controllers; Production process: FR4 double-sided tin plating;

Shape design: non-slip half-moon groove.

Specification:

- Working voltage: DC 5V;
- Working current: 20mA;
- Sensor type: analog signal;
- Working temperature: 10°C -30°C;
- Working humidity: 10%-90% non-condensing

Wiring Up

Insert micro:bit onto EASY Plug shield, connect water level sensor and LED module to P1 and P12 port of shield with two RJ11 cables.



Note: Dial Voltmeter_Switch to 3V end.

Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference. Notethe analog value can be adjusted



Test Result

Wiring up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

Open CoolTerm, click Options and select SerialPort, set COM port and baud rate, set baud rate to 115200. Tap OK and Connect.

The deeper the water level sensor is immersed, the analog value gets larger and larger; on the contrary, the analog value will plummet. When the analog value is greater than 400, passive buzzer will sound and LED will flash; if not, LED

✓ Untitled_0 *		_		<
File Edit Connection View Window Help				
New Open Save Image: Connect Disconnect Image: Clear	Data Options	HEX View Hex	? Help	
value:48				^
value:52				
value:50				
value:58				
value:57				
value:64				
value:78				
value:83				
value:90				
value:91				
value:104				
value:112				
value:125				
value:142				
value:181				
value:297				
value:388				
value:403				
value:500				
varac. 525				¥
COM16 / 115200 8-N-1	TX 😽 RT	5 😝 DTR	OCD	
Connected 00:40:48	S RX CTS	S 🕘 DSR	🌒 RI	

will be off and buzzer won't emit sound.

6.32 Project 32: 1602 LCD Display

1.Description

1602 I2C can be used as display, in this project, we will connect it to shield and teach you how to make it display"keyestudio" and numbers.

2. What You Need:

- Micro:bit*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY plug LCD 1602 I2C Module*1
- RJ11 Cable*1
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

3. EASY Plug LCD 1602 I2C Module:



This module is a LCD 16x2 display, useful for creating standalone projects.

- 1 16 characters wide, 2 rows;
- 1 White text on blue background;
- 1 Chip Operating Voltage: 4.5-5.5V
- 1 Working Current: 2.0mA (5.0V)
- 1 Optimum working voltage of the module is 5.0V
- 1 Single LED backlight included can be dimmed easily with a resistor.
- 1 Built in character set supports English text
- 1 Comes with necessary contrast potentiometer

4. Wiring Up

Insert micro:bit onto EASY Plug shield, connect LCD 1602 I2C to I2C port of shield with a RJ11 cable, and plug in power.



5. Test Code

Enter link: https://makecode.micro:bit.org/ to edit program, and set test code with library, as shown below:



Download library

https://github.com/xuefengedu/pxt-lcd1602_CN

Copy this link in the search box to search:

🗲 Go back						
	https://github.com/xuefen	gedu/pxt-lcd1602_CN Icd1602 LCD1602液晶microbit扩展包	Q			
		User-provided extension, not endorsed by Microsoft. Learn more				

Tap"lcd1602"to download, then LCD 1602 module will be added in the editing blocks, as shown below:



Test Code



6.Test Result

Wiring up, dial Voltmeter_Switch to 5V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

You will see"Keyestudio"at first row and numbers at the second row.

Note: Press the reset button if there is random code on 1602 LCD module)

6.33 Project 33: Vapor in the Air

1.Description

We could use vapor sensor to detect the vapor content in the air. The analog value will be displayed on 1602 LCD and CoolTerm serial monitor.

2.What You Need:

- Micro:bit Board*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY Plug Vapor Sensor*1
- EASY Plug LCD 1602 I2C Module*1
- RJ11 Cable*2
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug Vapor Sensor:



Vapor sensor is an analog sensor and can be made as a simple rainwater detector and liquid level switch. When humidity on the face of this sensor rises, the output voltage will increase.

3. Specification:

- Working Voltage: 3.3V-5V
- Working Current: <20mA
- Working Temperature: 10°C70°C
- Interface Type: EASY plug

4.Wiring Up

Insert micro:bit onto EASY Plug shield, connect vapor sensor and 1602LCD to P1 and I2C port of shield.



Note: Dial Voltmeter_Switch to 5V end.

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

The below example code is as for your reference, you need to add the library of LCD 1602 module

3	Game
	Images
0	Pins
•4	Serial
	Control
0	Extensions

Download library

https://github.com/xuefengedu/pxt-lcd1602_CN

Copy this link in the search box to search.

🗲 Go back		Extensions						
	https://github.com/xuefen	gedu/pxt-lcd1602_CN	٩					
		Icd1602 LCD1602液晶microbit扩展包						
		User-provided extension, not endorsed by Microsoft. Learn more						

Click"lcd1602"to download, then LCD 1602 module will be added in editing blocks



6. Test Code



6.Test Result

Wiring up, dial Voltmeter_Switch to 5V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

Open CoolTerm, click Options and select SerialPort, set COM port and baud rate, set baud rate to 115200. Tap OK and Connect.

CoolTerm monitor and 1602 LCD module display the analog signals read by steam sensor, the higher the vapor content is, the larger the analog value, as shown below:

Note: Press the reset button if there is random code on 1602 LCD module)

CoolTerm monitor shows the analog signals read by vapor sensor, the higher the vapor content, the larger the analog value is, as shown below:

🐠 U	ntitled_() *										\times	
File	Edit C	onnectio	on View \	Nindow	Help								
New	(1) Open	E Save	Connect	Disconn	ect	Clear Data	Op	tions	H Viev	EX v Hex	He	elp	
steam	conter	nt:477											^
steam	conter	nt:546											
steam	conter	nt:556											
steam	conter	nt:536											
steam	conter	nt:575											
steam	conter	nt:618											
steam	conter	nt:655											
steam	conter	nt:627											
steam	conter	nt:611											
steam	conter	nt:672											
steam	conter	nt:673											
steam	conter	nt:705											
steam	contei	nt:729											
steam	contei	nt:669											
steam	contei	nt:/21											
steam	contei	nt:/48											
steam	contei	ht:/16											
steam	conter	10:098										- 1	
steam	conter	10:770											
steam	conter	10:790											
steam	conter	16:703											
steam	conte	nt . 972											
steam	conte	nt • 931											
oteam	conte	nt • 884											
oteam	conte	nt • 002											
Sceam	CONCE	10.902											
													5
CO	M16 / 11	5200 8-N	-1				ТХ			DTR	•	DCD	
Cor	nocted	00.00.57					DV	Сто		DCP		1	
Cor	metted	00:00:37								Dav		M .	

6.34 Project 34: Pressure Detection

1.Description

We've learned different sensors with specific characteristics, like sound sensor, gas sensor and so on. In this experiment, we will measure the pressure with thin-film pressure sensor and micro:bit.

2. What You Need:

- Micro:bit Board*1
- EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY Plug thin-film pressure sensor*1

- RJ11 Cable*1
- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug Thin-film Pressure Sensor



This EASY plug pressure sensor adopts the flexible Nano pressure-sensitive material with an ultra-thin film pad. It has the functions of water-proof and pressure detection. The force sensors are ultra-thin and flexible printed circuits, which can be easily integrated into force measurement applications.

3. Specification:

- Range: 0-10KG
- Working Voltage: DC 3.3V—5V
- Thickness: 0.25mm
- Response Point: 20g
- Repeatability: $\pm 5.8\%50\%$ load
- Accuracy: ±2.5%85% range interval
- Durability: 100 thousand times
- Initial Resistance: 100M(no load)
- Response Time: 1ms
- Recovery Time: 15ms
- Working Temperature: 20°C—60°C

4.Wiring Up

Insert micro:bit onto EASY Plug shield, connect thin-film pressure sensor to P1 port of shield.



NoteDial Voltmeter_Switch to 3 V end.

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

on start	"on start" : command block only runs once to start program.
clear screen	Turn off LED dot matrix
forever	The program under the block "forever" runs cyclically.
show number analog read pin P1 •	Micro:bit shows the analog signals read by by thin-film pressure sensor
pause (ms) 100	Delay in 100ms
serial write value value analog read pin P1 •	Serial writes value=analog signals read by thin-film pressure sensor

6.Test Result

Wiring up, dial Voltmeter_Switch to 3V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

Open CoolTerm, click Options and select SerialPort, set COM port and baud rate, set baud rate to 115200. Tap OK and Connect.

Read the analog value of P1 end when the thin film is not pressed; when pressed, the bigger the pressure on thin film is, the larger the analog value is, as shown below:

✓ Untitled_0 *	_		×
File Edit Connection View Window Help			
Image: New Open SaveImage: SaveI	HEX View He	x Help	
value:141			^
value:141			100
value:142			
Value:144			
Value:13/			
value:151			
value: 300			
value: 360			
value: 394			
value:556			
value:551			
value:600			
value:692			
value:745			
value:742			
value:761			
value:818			
value:877			
			\checkmark
COM16 / 115200 -N-1	S 🕒 DTF	R 🍈 DC	D
Connected 00:14:44 ORX CT	S 🍈 DSR	🕘 RI	

6.35 Project 35: Make A Thermo-hygrometer

1.Description

This DHT11 Temperature and Humidity Sensor is a composite sensor which contains a calibrated digital signal output of the temperature and humidity.

Its technology ensures high reliability and excellent long-term stability.

In this experiment, we connect DHT11 temperature and humidity sensor to P1 of micro:bit. We could calculate the current temperature and humidity value with specific formula to read the data.

And CoolTerm and 1602 LCD module will display temperature and humidity value too.

2. What You Need:

- Micro:bit Board*1EASY Plug Shield for micro bit V1.1*1
- Micro USB Cable*1
- EASY plug DHT11 Temperature and Humidity Sensor*1
- EASY plug 1602 LCD Module*1
- RJ11 Cable*2

- 6 AA Battery Holder*1
- 1.5V AA Battery*6

EASY Plug DHT11 Temperature and Humidity Sensor:



DHT11 temperature and humidity sensor, super low cost, adopts a capacitive humidity sensor and a thermistor to measure data and output a pre-calibrated digital signal. It has characteristics with high response, anti-interference ability, reliability and long-term stability.

3. Specification

This DHT11 Temperature and Humidity Sensor is a composite sensor which contains a calibrated digital signal output of the temperature and humidity.

Its technology ensures high reliability and excellent long-term stability.

In this experiment, we connect DHT11 temperature and humidity sensor to P1 of micro:bit. We could calculate the current temperature and humidity value with specific formula to read the data.

And CoolTerm and 1602 LCD module will display temperature and humidity value too.****

https://www.gstatic.cn/supportcn/translate/index

https://policies.google.com/?hl=zh-CN

- Power supply voltage: DC5V;
- Relative humidity and temperature measurement;
- Suitable for humidity reading 20%-90%, accuracy: 5%;
- Suitable for temperature readings of 0-50°C, accuracy: $\pm 2^{\circ}C$
- Interface: EASY plug
- Low cost

4.Wiring Up

Insert micro:bit onto EASY Plug shield, connect DHT11temperature and humidity sensor and 1602 I2C to P1 and I2C port of shield.



Dial Voltmeter_Switch to 5V end.

5.Test Code

You could navigate https://makecode.micro:bit.org/reference to have access to more details.

Browse link https://makecode.micro:bit.org/ to edit your program. The following test code is as for your reference.

We need to add the library of DHT11 temperature and humidity sensor.

00	Game
	Images
0	Pins
•🕁	Serial
188	Control
0	Extensions

Search"DHT11", as shown below, select and click"DHT11_DHT22"to install library

🗲 Go back	Extensions		
DHT1	11	٩)	
	BH122 5 + -		
	DHT11_DHT22 MakeCode extension for DHT11/DHT22 sensors	iot-environment-kit Environment and Science IoT Kit for micro:bit	
_	Learn more	Learn more	

After the successful installation, the DHT11 module will be added into the editing module, as shown below:



Then we add the library of 1602 I2C LCD module in same way.



Download library

https://github.com/xuefengedu/pxt-lcd1602_CN

Copy this link in the search box to search, as shown below:

🗲 Go back	Extensions	Extensions	
	https://github.com/xuefengedu/pxt-lcd1602_CN	٩	
	Icd1602 LCD1602液晶microbit扩展包		
	User-provided extension, not endorsed by Microsoft. Learn more		

Click "lcd1602" to download, LCD 1602 module will be added.



6. Complete Test Code



7. Test Result

Wiring up, dial Voltmeter_Switch to 5V end, plug in external power and dial Power_Switch to ON end and upload code to micro:bit.

Open CoolTerm, click Options and select SerialPort, set COM port and baud rate, set baud rate to 115200. Tap OK and Connect.

CoolTerm serial monitor and 1602 LCD module show the detected temperature and humidity, as shown below:

(Note: You could press reset button if there is random code on 1602 LCD module)

✓ Untitled_0 *	- 🗆 ×
File Edit Connection View Window Help	
Image: New Open Save Image: Save Image: Save Image: Save Image: Save	r Data Options View Hex Help
humid::67 temper::32.01	
humid::59 temper::32.09	
humid::61 temper::33.01	
humid::95 temper::34	
humid::95 temper::34.01	
humid::95 temper::34.01	
humid::95 temper::34.02	
COM16 / 115200 8-N-1 Connected 00:02:04	 TX RTS DTR DCD RX CTS DSR RI
CHAPTER

SEVEN

7.RESOURCES

https://fs.keyestudio.com/KS4020-4021